



1 HOW TO ATTACH THE CARRIER WAISTBELT

ES Cómo abastar el estribo de la mochila FR Comment attacher la ceinture ventrale du porte-bébé JP ウエストベルトの装着
 KR 캐리어 허리벨트 착용법 KC 如何繫上背帶的腰帶 KE 如何繫上背帶的腰帶

NEWBORN MODE
 <23 in | <58.4cm | 0 - 2m




BABY MODE
 >23 in | >58.4+ cm | >2m



2 FRONT CARRY INWARD-FACING (NEWBORN MODE)

ES Posición frontal mirando hacia dentro (modo recién nacido) FR Portage ventral face au porteur (position nouveau-né) JP 新生児対面抱き
 KR 마누해기 - 앞쪽이 안쪽으로 향함 (신생아 모드) KC 面朝內親胸正面背法 (新生兒模式) KE 面朝內親胸正面背法 (新生兒模式)


<23 in | <58.4cm
 0 - 2m



3 FRONT CARRY INWARD-FACING (BABY MODE)

ES Posición frontal mirando hacia dentro (modo bebé) FR Portage ventral face au porteur (position bébé) JP 対面抱き
 KR 마누해기 - 앞쪽이 안쪽으로 향함 (유아 모드) KC 面朝內親胸正面背法 (嬰兒模式) KE 面朝內親胸正面背法 (嬰兒模式)


>23 in | >58.4+ cm
 >2m



4 FRONT CARRY OUTWARD-FACING (BABY MODE)

ES Posición frontal mirando hacia fuera FR Portage ventral face au monde JP 前向き抱き
 KR 마누해기 - 앞쪽이 바깥쪽으로 향함 KC 面朝外親胸正面背法 KE 面朝外親胸正面背法


25 - 30 inches | 63.5 - 76.2 cm
 >5m



5 BACK CARRY (BABY MODE)

ES Posición en la espalda FR Portage dorsal JP おんぶ KC 뒤로 해기 KC 背面背法 KE 背面背法

>26 in | >66+ cm
 >6m




6 BABY POSITIONING CHECKLIST & TIPS

ES Guía de comprobación y consejos para la colocación del bebé FR Adress et conseils à consulter pour un positionnement correct du bébé
 JP お子さまの位置や姿勢のチェックと調整 KR 아이 자세를 위한 체크리스트와 팁
 KC 正確的嬰兒坐姿及溫馨提示 KE 正確的嬰兒坐姿及溫馨提示




BABY CARRIER PARTS




- 1 chest strap buckle
- 2 back/chest strap slider
- 3 shaped shoulder strap
- 4 head and neck support
- 5 Ergobaby logo
- 6 Adjuster for seat adjustment (face in or out)
- 7 lumbar support
- 8 waistbelt buckle
- 9 pocket
- 10 safety elastic loop

AGES AND STAGES - GENERAL GUIDELINES



INSTRUCTION MANUAL



AERLOOM BABY CARRIER

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE



THE ERGO BABY CARRIER, INC.
 US: 617 West 7th St., Ste. 1000, Los Angeles, CA 90017
 +1 213 283 2090 | support@ergobaby.com
 EU: Mönckebergstraße 11, 20095 Hamburg, Germany
 +49 40 421 065 0 | customersupport@ergobaby.eu

More tips and videos on ergobaby.com

IM-BCAERROW-200610-V1