




OSGIKEN Corvette C5 Release Sleeve Set Installation Manual



Enclosed Items in the Kit (Picture H)

- Return Spring (No.4)
- Release Sleeve Bearing (No.3)

Installation

1. Remove genuine direct release sleeve assembly from your vehicle (See Picture A).
2. Remove genuine release sleeve bearing (No.1) and return spring (No.2), Reference Picture B and C.
You do not need genuine release sleeve bearing (No.1) and return spring (No.2) for this installation.
3. Install OS return spring (No.4) and OS release sleeve bearing (No.3), Reference Picture D.
4. OS release sleeve set installation is completed (Picture E) and install the direct release sleeve assembly to original location.

General Warning

- ※Check to see if all the parts are enclosed.
- ※ Please be aware of potential risks and hazards when installing our products. We do not take any responsibility for any loss and/or injury occurred when our products are modified, re-used and/or ill-fitted.
- ※Spray aerosol lubricant to the appropriate surface of the moving parts. Periodical lubrication is recommended.
- ※All information on this sheet is based on Japanese model vehicle and may not be applied to vehicles in your country.
- ※Specification may be changed without notice.

OSGIKEN
Pursuing Power Link &
Parts Development

464 OKIMOTO NAKAKU OKAYAMA 702-8001 TEL.(086)277-6609 FAX(086)277-8115

URL:www.osgiken.co.jp/