





# OSGIKEN Corvette Release Sleeve Set Installation Manual



## Enclosed Items in the Kit (Picture H)

- Return Spring (No1)
- Release Sleeve Stopper (No2)
- Release Sleeve Bearing (No3)

## Installation

1. Remove genuine direct release sleeve assembly from your vehicle (See Picture A).
2. Remove genuine release sleeve stopper (No6) to disassemble the direct release sleeve assembly (See Picture B and C). You do not need genuine return spring (No4), release sleeve bearing (No5) and release sleeve stopper (No6) for this installation.
3. Install OS return spring (No1) instead of genuine return spring (No4) (See Picture D).
4. Install genuine boot cover assembly (No7), OS sleeve bearing (No3) and release sleeve stopper (No2) (See Picture E).
5. Make sure that the stopper is properly installed (See Picture F).
6. OS release sleeve set installation is completed (Picture G) and install the direct release sleeve assembly to original location.

## General Warning

- ※ Check to see if all the parts are enclosed.
- ※ Please be aware of potential risks and hazards when installing our products. We do not take any responsibility for any loss and/or injury occurred when our products are modified, re-used and/or ill-fitted.
- ※ Spray aerosol lubricant to the appropriate surface of the moving parts.  
Periodical lubrication is recommended.
- ※ All information on this sheet is based on Japanese model vehicle and may not be applied to vehicles in your country.
- ※ Specification may be changed without notice.

OSGIKEN

464 OKIMOTO OKAYAMA-CITY OKAYAMA 702-8001 TEL(086)277-8609 FAX(086)277-8115

URL: [www.osgiken.co.jp/](http://www.osgiken.co.jp/)