

# HONDA CTX-1300

## Parts list for MCS 6340 kit

<u>Item</u>	<u>Qty</u>	<u>Part Number</u>	<u>Description</u>
1	1	MCS 8000C	Computer
2	2 lengths		Self-Adhesive Velcro 8cm long
		<u>MCS 6342</u>	<u>Electric throttle servo assembly</u>
3	1	MCS 850	Electric throttle servo
4	1	MCS 850C	Servo nose
5	3		M4 x 12 pan head screws
6	1		3/4" x 3/32" (19 x 3mm) 'O' ring
7	1	MCS 850B	Cable sealing boot
8	2	MCS 054	Wire ring cable retainer (1 spare)
9	1 length		Self-Adhesive Velcro 8cm long
10	1	MCSSC 500	Throttle servo cable
11	1	<u>MCS 6341</u>	<u>Wiring harness</u>
a			Computer plug (26 pin)
b			Fuse holder (3 amp fuse)
c			Tach signal (yellow wire)
d			Speed sensor (blue/black wires)
e			Servo plug (4 pin)
f			Power & brake sensor plugs (orange and grey wires)
g			Ground connector (black wire)
h			Clutch sensor (blue wire)
i			Control switch plug (6 pin)
		<u>MCS 6344</u>	<u>Control Switch assembly</u>
12	1	MCS 820-90	Control Switch
13	1	MCS 831N	Switch bracket
	4		4 gauge x 1/2" pan head self tap screw
14		<u>MCS 6345</u>	<u>Cable Interface Unit (CIU) assembly</u>
15	1	MCS 6345A	CIU housing
16	1	MCS 003F	Throttle Servo spool
17	1	MCS 6346	Dual spool
18	1	MCS 003H	Bush
19	1	MCS 003K	End Cap
20	1		M5 x 45 pivot bolt
21	1		Pivot nut M5 Nyloc nut
22	2		5mm plated flat washer
23	1		M4 x 10 pan head screw (servo cable retainer)
24	1	MCSCC 100	Carburettor cable
	10		100mm cable ties
	10		150mm cable ties
	6		200mm cable ties
	6		300mm cable ties
	1 bottle		Throttle cable oil (Singer industrial sewing machine oil)

Information, Set up and Operation Manual  
Operation and User Manual

# Installation Manual

## Trouble shooting guide

