

# HONDA VFR1200X Crosstourer & Crosstourer DCT

## Parts list for MCS 7030aT kit for VFR1200X (manual transmission)

## Parts list for MCS 7030aT DCT kit for VFR1200X-DCT (DCT automatic transmission)

<u>Item</u>	<u>Qty</u>	<u>Part Number</u>	<u>Description</u>
1	1	MCS 7030aTBW	Computer
2	2 lengths		Self-adhesive Velcro (2 x 8cm pieces)
		<u>MCS 4954</u>	<u>Control Switch assembly (Manual &amp; DCT)</u>
3	1	MCS 820-160	Control Switch (left side mounting)
4	1	MCS 831A	Switch bracket (above handlebar mounting Manual & DCT)
OR			
5	1	MCS 831A	Switch bracket (below handlebar mounting – Manual only)
(Note: - Same switch bracket used, bracket is reversed to change mounting position)			
	4		4 gauge x 1/2" pan head self-tap screw
		<u>MCS 6034</u>	<u>Control Switch assembly (for DCT)</u>
6	1	MCS 826-90	Control Switch (right side mounting)
7	1	MCS 831A	Switch bracket (above handlebar mounting)
OR			
8	1	MCS 831A	Switch bracket (below handlebar mounting)
(Note: - Same switch bracket used, bracket is reversed to change mounting position)			
	4		4 gauge x 1/2" pan head self-tap screw
9	1	<u>MCS 7035T</u>	<u>Wiring harness (for manual shift models)</u>
OR	1	<u>MCS 7035T DCT-LH</u>	<u>Wiring harness (for DCT models – Left side switch</u>
OR	1	<u>MCS 7035T DCT-RH</u>	<u>Wiring harness (for DCT models – Right side switch</u>
a			Computer plug (26 pin)
b			Fuse holder (3 amp fuse)
c			TPS connectors (3 pin)
c1			TPS connector housing and retainer
d			Tach sensor (yellow wire)
d1			Tach sensor connector housing
e			Speed sensor connectors (blue/black wires)
f			Power & brake sensor (orange and grey wires)
g	Not fitted on DCT version		Clutch sensor (blue wire)
h1			Control switch plug (6 pin) (LEFT SWITCH ONLY)
h2			Control switch plug (6 pin) (RIGHT SWITCH ONLY)
<u>New Slim Control Switch Options.</u>			
10		GT-1014-160	Slim Control Switch
11		GT-1014-160-831A2-SL	Below Bar Slim Control Switch
	10		100mm cable ties
	10		150mm cable ties
	10		200mm cable ties

### OPTIONAL

Terminal extractor set

Information, Set up and Operation Manual



Operation and User Manual

Installation Manual


Trouble shooting guide






2




10



11



9




b

h1 (LEFT SIDE SWITCH only)

h2 (RIGHT SIDE SWITCH only)



e



g (MANUAL only)