



PAIRING

- ▶ Press and hold the center button for ~8 seconds to begin the pairing process. You will hear a prompt confirming pairing has begun. The Crescent's LED will flash red and blue to indicate it is searching for devices.
- ▶ Open your device's Bluetooth preferences and select "LSTN Crescent" You will hear a confirmation in the earbuds.
- ▶ That's it! You're now ready to enjoy your music, movies, audiobooks, and more. Your earbuds will automatically connect to the last device they were paired with the next time you turn them on.
- ▶ To pair your earbuds to a different device, simply power them off, then begin the process from the beginning. You can also "Forget" the Crescent from your device.

USE AND FUNCTION

Playback Control: Tap the plus (+) or minus (-) button to raise or lower volume. Hold the plus (+) button to skip one track, and the minus (-) button to go back one track.

Phone Calls: Tap the center (○) button to answer an incoming phone call, or double-tap to ignore. While on a call, press the same button again to hang up.



S P E C I F I C A T I O N S A N D F E A T U R E S

- ▶ Battery life: apx. 2 hours
- ▶ Charge time: 1 hour
- ▶ In-line microphone
- ▶ Playback controls
- ▶ Multiple sizes of ear tips
- ▶ Driver: 10mm neodymium
- ▶ 16 Ω impedance
- ▶ Operating range: 30' / 10m
- ▶ Cable length: 1.5' / .6m
- ▶ Bluetooth 4.2

T R O U B L E S H O O T I N G

- ▶ If you are having trouble connecting, try turning off both your earbuds and your playback device, then turning them back on again.
- ▶ If your connection is spotty or intermittent, you may be too far from your device. The Crescent works best within a 30-foot range of your device, with direct line-of-sight. If you keep your device in your back pocket, this can also cause a spotty or intermittent connection.

