



QUICK START GUIDE

Satellite Wireless Speaker

Thanks for purchasing LSTN's Satellite wireless speaker! We know you're anxious to get started, so we'll keep this short.

1) Press the power (⏻) button down for 3 seconds. Your speaker should begin looking for devices immediately, and the LED will begin to blink.

2) Open your device's Bluetooth preferences and select **LSTN-Satellite**. The Satellite will beep, and the LED will blink blue once paired.


3) That's it! You're now connected. To pair to a different device, hold the volume up (+) and down (-) buttons for approximately 6 seconds, and restart the pairing process at step 1.

After completing the initial pairing process, your Satellite will reconnect to the last used device once turned on - you do not need to re-pair it each time. You can also use the included audio cable to listen without connecting via Bluetooth. This guide is available online at lstnsound.co/gettingstarted.



OPERATION

Satellite Wireless Speaker



MUSIC PLAYBACK

Play / Pause: Quickly press the power (⏻) button

Adjust Volume: Press and hold the corresponding plus (+) or minus (-) button

Skip Track: Press the plus (+) button to skip forward one track, and the minus (-) button to go back one track

PHONE CALLS / OTHER

Answer / End Call: Quickly press the power (⏻) button

Redial: Quickly double-click the power (⏻) button

On / Off: Press the power (⏻) button for 3 seconds



TROUBLESHOOTING

Satellite Wireless Speaker

Something not working? Don't panic. Try these helpful tips, and if afterwards you're still stuck, contact us at hello@lstnsound.co

MY SATELLITE WON'T TURN ON

Check to ensure that your Satellite is charged. Plug the provided USB cable into a USB power supply. The LED indicator will turn red, and the speaker will begin charging. The LED will turn off once your Satellite is fully charged (apx. 3 hours).

MY SATELLITE WON'T PAIR / CONNECT

Sometimes, connection errors happen. Try turning your device's Bluetooth connection off for a few seconds, and then try pairing again. If that doesn't work, turn off both your device's Bluetooth and the speaker for ~10 seconds, then start again.

MY CONNECTION IS SPOTTY / INTERMITTENT

The Satellite's connection range is approximately 33 feet (10 m). Check to make sure you're in this range. It also works best with a direct line-of-sight connection, so make sure nothing is obstructing the path between your Satellite and your device.