



CARE INSTRUCTIONS

FABRIC CARE

IN GENERAL, REGULAR ROTATION AND FLUFFING OF YOUR SEAT AND BACK CUSHIONS IS IMPORTANT FOR THE LONGEVITY OF YOUR LEE FURNITURE. WE RECOMMEND VACUUMING WITH A SOFT BRUSH ATTACHMENT TO REMOVE DUST AND DEBRIS. WHEN PURCHASING LEE UPHOLSTERY, ASK YOUR RETAILER FOR SPECIFIC CLEANING CODES FOR THE FABRIC YOU HAVE CHOSEN. HAVING THE CORRECT CLEANING SOLUTIONS ON HAND WILL ALLOW YOU TO RESPOND QUICKLY TO UNEXPECTED SPILLS. WHEN CLEANING A SPOT OR STAIN, ALWAYS PRE-TEST A SMALL, INCONSPICUOUS AREA BEFORE PROCEEDING. CLEAN FROM THE OUTSIDE TO THE MIDDLE OF THE AFFECTED AREA TO PREVENT WATER MARKS. IF THE OVERALL CONDITION OF YOUR FURNITURE IS SOILED, CONSULT A PROFESSIONAL UPHOLSTERY CLEANING SERVICE.

LEATHER CARE

LEATHER IS A NATURAL PRODUCT AND NO TWO HIDES ARE ALIKE. DISTINCT CHARACTERISTICS ARE A RESULT OF ENVIRONMENTAL FACTORS AND SHOULD NOT BE CONSIDERED DEFECTS. THESE INCLUDE, BUT ARE NOT LIMITED TO HEALED SCARS, NATURAL WRINKLES, BITE AND SCRAPE MARKS, AND COLOR VARIATIONS. FOR CONTINUED MAINTENANCE ON YOUR LEATHER PIECE, OCCASIONALLY WIPE WITH A DRY, CLEAN CLOTH TO PREVENT DUST BUILD UP. ANY SPILLS SHOULD BE BLOTTED IMMEDIATELY WITH A CLEAN CLOTH. SHOULD A STAIN PROVE DIFFICULT TO CLEAN, USE DISTILLED WATER ON A LIGHTLY DAMP CLOTH TO BLOT THE STAIN. ALWAYS PRE-TEST AN INCONSPICUOUS AREA BEFORE PROCEEDING. ALLOW THE LEATHER TO DRY NATURALLY. LEATHER PRODUCTS WILL FADE IN DIRECT SUNLIGHT.

SLIPCOVER CARE

IN GENERAL, REGULAR ROTATION AND FLUFFING OF YOUR SEAT AND BACK CUSHIONS IS IMPORTANT FOR THE LONGEVITY OF YOUR LEE FURNITURE. WE RECOMMEND VACUUMING WITH A SOFT BRUSH ATTACHMENT TO REMOVE DUST AND DEBRIS. WHEN PURCHASING LEE UPHOLSTERY, ASK YOUR RETAILER FOR SPECIFIC CLEANING CODES FOR THE FABRIC YOU HAVE CHOSEN. BEFORE REMOVING THE SLIPCOVER FOR CLEANING, BE CERTAIN TO NOTE HOW THE COVER IS APPLIED SO THAT YOU CAN RECOVER CORRECTLY. IF THE SLIPCOVER FABRIC IS DRY CLEAN ONLY, IT IS RECOMMENDED THAT YOU USE A PROFESSIONAL DRY CLEANING SERVICE. IF MACHINE WASHING IS RECOMMENDED, REMOVE THE SLIPCOVER FROM ONE OF THE ARMS OF THE PIECE AND WORK AROUND TO THE BACK OF THE FRAME AND TO THE OPPOSITE ARM. THE SEAMS ON YOUR SLIPCOVER HAVE BEEN SURGED AND OVERLOCKED TO PREVENT FRAYING, BUT WE RECOMMEND ZIPPING ALL CUSHION AND THROW PILLOW CASINGS BEFORE WASHING. USING THE GENTLE CYCLE ON YOUR WASHING MACHINE, WASH THE SLIPCOVER IN COLD WATER WITH A MILD DETERGENT. BE CAREFUL NOT TO OVERLOAD THE CAPACITY OF YOUR WASHER. TUMBLE DRY FOR THREE MINUTES ON LOW HEAT, NO HIGHER THAN 140 F, AND THEN CONTINUE TO TUMBLE DRY USING THE AIR CYCLE. RETURN THE SLIPCOVER, SLIGHTLY DAMP, TO THE FRAME STARTING AT THE BACK OF THE FRAME AND WORKING FROM ARM TO ARM. CLEAN ALL PARTS OF THE SLIPCOVER TO AVOID COLOR VARIATION. MACHINE WASHING IS NOT RECOMMENDED FOR MULTIPLE FABRIC SLIPCOVERS. WHEN STORING SLIPCOVERS, PLACE IN A COOL, DRY AREA, OUT OF DIRECT LIGHT. PRIOR TO STORAGE, WRAP IN A LIGHT WEIGHT WHITE SHEET OR MUSLIN COVER TO HELP AIR CIRCULATE AND KEEP DUST FREE.

UNCOVERED CARE

ALL FULLY UPHOLSTERED OUTDOOR FURNITURE IS BUILT TO WITHSTAND THE NATURAL OUTDOOR ELEMENTS. FRAMES ARE MADE FROM MARINE GRADE PLYWOOD, BUILT IN SLOPING DRAINS, RETICULATED FOAM, AND STAINLESS STEEL STAPLES AND GALVANIZED SCREWS. IF YOUR PIECES ARE SLIPCOVERED, REMOVE THE COVER AND PLACE IN A WASHING MACHINE ON A COLD TEMPERATURE SETTING. BLEACH AND DETERGENT CAN BE USED. AIR DRY YOUR SLIPCOVERS AND REPLACE THE COVERS TO THE FRAME. IF YOUR PRODUCTS ARE FULLY UPHOLSTERED, SPRAY THE PIECE WITH A CLEANING AGENT, USING A SOFT BRISTLE BRUSH TO CLEAN. RINSE WITH A WATER HOSE AND LET THE PIECE DRY NATURALLY.

FOR A PROFESSIONAL, CERTIFIED UPHOLSTERY CLEANER IN YOUR AREA, HELPFUL CLEANING TIPS, ADDITIONAL MAINTENANCE SUGGESTIONS FOR UPHOLSTERY FABRICS AND LEATHERS, VISIT WWW.IICRC.ORG