

Vanmate™



Instruction Manual

Vanmate Motion

Table Of Contents

TABLE OF CONTENTS 2

GENERAL NOTES 3

BOX CONTENTS..... 3

PRODUCT DIAGRAM 3

INSTALLATION..... 4

SETUP (FIRST USE) 4

OPERATING INSTRUCTIONS..... 4

REMOTE CONTROL (FOB) – PAIRING GUIDE 5

REPLACING THE BATTERIES 6

FACTORY RESET 6

SUPPORT 6

General Notes

IMPORTANT: Please also refer to buy.vanmate.co for further information and technical assistance. We are Improving our site continuously to make sure you have the best possible experience with our products. we normally respond within 24 hours to any questions.

The vanmate motion sensor alarm can be operated directly on the device or with a remote control. If required, you can link multiple remote controls to one alarm and/or multiple alarms to one remote control, see associated instructions.

Box Contents

- 1 x Vanmate PIR motion sensor alarm
- 1 x Remote control
- 3 x Batteries AAA alkaline - if you want even longer life we recommend Duracel batteries.
- Flexible mount
- Pair of screws
- Double sided adhesive
- Bracket Sticker
- Instructions for use

Product Diagram

- A. Siren
- B. Detection window
- C. Mode button (🎵)
- D. On/Off button (⚙️)
- E. Pairing button (📶)
- F. Disarm: deactivate the Alarm Unit
- G. Arm button: activate the Alarm Unit
- H. Switch Voice: Switch from Chime to Siren and vice versa
- I. Bell button: triggers a loud emergency alarm




Installation

1. The motion alarm detects movement within a 180 degree range. Find a position for the unit that faces the point of entry and area that needs to be protected. Ensure there are no obstructions e.g. curtains.
2. Slide off the lid on the alarm unit & insert 3 AAA batteries, close the lid again.
3. Install the unit using the supplied screws or double sided adhesive.
4. To ensure that the positioning of the PIR sensor stays fixed in position and to hold the vanmate alarm module in place it is advised that you use the adhesive tape supplied as per below:



Setup (First Use)

Switching ON Vanmate for the first time:


Long press the On/Off button () on the Alarm' Unit. There will be one short beep and the red detection light on the front will light up once. This means the unit is now switched on. The factory settings are such that the vanmate alarm will startup in armed mode.


Operating Instructions


Note - There are two ways to press the buttons on the alarm:

- **Short press** = press the button for less than 1 second.
- **Long press** = keep the button pressed in for 5 seconds or more.






IMPORTANT: Please note that switching the unit On/Off and arming it are two individual steps. Switching it on does NOT automatically mean that the unit is armed and active because the PIR motion sensor alarm is equipped with a memory function which allows the unit to come back to resume in its last setting after switching off. If that setting was 'armed' it will come back to that setting. If the setting was 'disarmed', it will be disarmed at start up.

Arming the PIR motion sensor: Press the On/Off button () shortly. You will hear one beep and the detector light will light up once. Your PIR motion sensor alarm is now armed. Alternatively, press the Arm button on the remote control.

Dis-arming the vanmate motion sensor: Press the On/Off button () shortly. You will hear two beeps and the detector light will light two times. Your PIR motion sensor alarm is now disarmed. Alternatively, press the disarm button on the remote control.



Changing the sound: Short press the Mode button () to change between sounds. Each time the button is pressed, a short sample of the chosen sound is heard (Siren or Chime).

Stopping the Siren alarm sound: There are three ways to stop the siren alarm sound:

1. Short press the Mode button () or the Pairing button (). The sound will stop and the unit will stay armed.
2. Short press the On/Off button () on the Alarm Unit. There will be two short beeps and the alarm sound will stop. The vanmate motion sensor alarm is now disarmed. Short press the On/Off button () again to arm it again.
3. Press the Arm or Disarm button on the remote control. In case of pressing the Arm button the alarm stops and the unit stays armed. When pressing the Disarm button the alarm stops and the unit changes in the disarmed mode at the same time. Switching the unit OFF: Long press the On/Off button () on the Alarm Unit. There will be one long beep and the red detection light in the front will light up once.

Remote Control (FOB) – Pairing Guide

Vanmate motion will come already paired with the supplied remote control. Pairing any additional remotes or re-pairing the original remote is a simple process.

1. Make sure the vanmate motion alarm unit is ON.
2. Long press the Pairing button () to enter pairing mode. The detector light will light up continuously.
3. Press any button on the remote control. You will hear two beeps to indicate correct pairing.
4. Repeat the above step for any additional remotes you would like to pair.
5. Short press the Pairing button () to exit the pairing mode. Your remote(s) have now been paired.

Note - Multiple remotes can be connected to any vanmate motion alarm unit. Also, the remote can also be linked to multiple vanmate motion alarms by using the exact same method described.

Replacing the batteries

IMPORTANT: When the batteries are running empty the detector light will flash once every 40 seconds and a beeping sound will be heard. Please change the batteries at your earliest convenience.

Remote control

The battery can be changed by removing the screw on the back of the remote control. Remove the back panel and replace the battery. The battery type is CR2032 (3V, Lithium battery).

PIR motion sensor alarm: Slide off the back panel and replace the batteries with 3x AAA size 1.5V Alkaline batteries.

Factory Reset

Reset to Factory settings: Follow this procedure to reset the vanmate motion sensor alarm back to the factory settings and disconnect any remote controls and emergency sensors. - Make sure the device is switched On.

Remove one or all the batteries. - Press the Mode button (🎵) and keep it pressed throughout the next 2 events:

1. Re-insert the battery.
2. 10 beeps will be heard and then another 5 beeps very quickly, Now, release the Pairing button. The factory reset is now completed. Your PIR motion sensor alarm is reset and will resume in Armed mode.

Support

If you have any questions please visit buy.vanmate.co or email support@vanmate.co