

DIODE FAQ's


Diode Instructions and Frequently Asked Questions

What is the diode for?

Different vehicles use different systems for high beam control. The diode allows different vehicles to keep their high beams plug and play with Dapper Lighting headlights.

Which way should I install the diode on my car?

Test out both RED RED BLACK BLACK or RED BLACK RED BLACK. If your headlights and high beams are operating properly, than leave the diodes as they are.





My headlights shutoff when I flip the high beams.

Switch the polarity on the diode. Your headlights low and high beams should be functioning properly.

The high/low function still isn't working correctly and I've

Double-check all of your connections starting from your stock harness (including positive and ground connections, stock H4 plug, and the Dapper Lighting high beam switch wiring.

Occasionally a pin can come out of a socket and cause the high beams to function incorrectly.

If you are still having problems, please contact us at **support@dapperlighting.com** for immediate assistance.

