



FIELD DESTROY GUIDE

LED Bulbs

DISCLAIMER:

Before removing the defective bulb make sure the bulb is disconnected and not receiving any power.

Tools Required:

- Defective bulb
- Wire cutter/sharp scissors



STEP 1:

Carefully remove the defective bulb from the vehicle.



STEP 2:

Locate where the wire comes out of the body of the bulb.



STEP 3:

With the wire cutter or sharp scissors, cut the wire.



a.



b.



c.

STEP 4:

Write your RMA number on sheet of paper (if you were not given an RMA number, skip this step).

STEP 5:

Take a picture of the cut bulb with the, optional, RMA number visible.

