



Airbrush Pen



Art Pen



Grip Pen



Standard Nibs



Felt Nibs



Flex Nibs



Wacom Pro Pen 2



Wacom Pro Pen slim



Wacom Pro Pen 3D



Wacom One Pen



Pro Pen 2 Standard Nibs



Pro Pen 2 Felt Nibs




Wacom One Pen Nibs



Wacom Adjustable Stand
(For Wacom Cintiq 16)



Wacom Adjustable Stand
(For Wacom Cintiq 22)



Wacom Stand
(for Wacom Cintiq Pro 13 & 16
and Wacom MobileStudio Pro 1.5)



Ergo Stand
(for Wacom Cintiq Pro 24)



Ergo Stand
(for Wacom Cintiq Pro 32)



Wacom Flex Arm
(for Wacom Cintiq Pro 24 & 32)



Wacom VESA Mount
(for Wacom Cintiq Pro 24 & 32 with
3rd party VESA display arms)



ExpressKey Remote



Wacom Link Plus



Wacom Color Manager





Pens & Nibs

Stands

Miscellaneous

Display Accessories		Cintiq		Wacom One	Wacom Cintiq		Wacom Cintiq Pro				Wacom MobileStudio Pro	
		Part Numbers	DTK2200 DTH2200	DTK2700 DTH2700	DTC133	DTK1660	DTK2260	DTH1320	DTH1620	DTK2420 DTH2420	DTH3220	DTHW1321
Airbrush Pen (2048 pressure levels)	KP400E	X	X		X	X	X	X	X	X	X	X
Art Pen (2048 pressure levels)	KP701E	X	X		X	X	X	X	X	X	X	X
Wacom Grip Pen (2048 pressure levels)	KP501E2	*	X		X	X	X	X	X	X	X	X
Standard Pen Nibs (5 pack)	ACK20001	X	X									
Hard Felt Pen Nibs (5 pack)	ACK20003	X	X									
Flex Pen Nibs (5 pack)	ACK20004	X	X									
Wacom Pro Pen 2 (8192 pressure levels)	KP504E				*	*	*	*	*	*	*	*
Wacom Pro Pen slim (8192 pressure levels)	KP301E00DZ				X	X	X	X	X	X	X	X
Wacom Pro Pen 3D (8192 pressure levels)	KP505				X	X	X	X	X	X	X	X
Wacom Pro Pen 2 Standard Nibs (10 pack)	ACK22211				X	X	X	X	X	X	X	X
Wacom Pro Pen 2 Felt Nibs (10 pack)	ACK22213						X	X	X	X	X	X
Wacom One Pen	CP91300B2Z			*								
Wacom One Pen Nibs	ACK24501Z			X								
Wacom Adjustable Stand for Cintiq 16	ACK620K				X							
Wacom Adjustable Stand for Cintiq 22	ACK639KZ					X						
Wacom Stand Cintiq Pro (For Cintiq Pro 13, 16 and MobileStudio Pro 15)	ACK62701K						X	X			*	*
Wacom Cintiq Pro 24 Ergo Stand	ACK62801								X			
Wacom Cintiq Pro 32 Ergo Stand	ACK62802									X		
Wacom Flex Arm	ACK62803K								X	X		
Wacom VESA Mount (For 3rd party VESA display arms)	ACK62804K								X	X		
ExpressKey Remote	ACK411050	X	*	X	X	X	X	X	*	*	X	X
Wacom Color Manager	EODIS3-DCWA	X	X	X	X	X	X	X	X	X	X	X
Wacom Link Plus	ACK42819						X	X				
MobileStudio Pro Power Adapter 100W (Mickey Mouse head)	ACK42714										*	*
Wacom Cintiq 16 AC Adapter (Standard PC head)	ACK43914Z				*							
Wacom Cintiq 22 AC Adapter (Standard PC head)	ACK43614					*						
Wacom Cintiq Pro 13/16 Power Adapter - 45W (Mickey Mouse head)	ACK4281401						*	*				
Wacom Cintiq Pro 24/32 power Adapter - 180W (Mickey Mouse head)	ACK4281402								*	*		
Wacom Cintiq 16 & 22 Power Cord - US (Standard PC head)	ACK43906USZ				*	*						
Wacom Power Cord - US (Mickey Mouse head)	ACK42806-US						*	*			*	*
Wacom One X-Shape Cable (X-Shape head)	ACK44506Z			*								
Wacom One Power adapter	ACK44501A			*								

Legend: X = Optional Accessory, * = Replacement Part (Included in box with main product) Note: This is a list of the most commonly purchased accessories and replacement parts. It is not a comprehensive list.