

GEORGE & WILLY®

SIGN SUPPLY CO.

ACRYLIC PAVEMENT SIGN

The Acrylic Pavement Sign offers a 40 x 80 cm of signage real estate to get your business noticed. It can be placed on the sidewalk or pavement in front of your store, coffee shop, or studio to help your business stand out.

The Acrylic Pavement Sign stands up to the elements without weathering.

Signs are provided blank and made from acrylic. For a message or decal, ask your local signwriter to apply a vinyl sticker.

Thank you for your purchase,

George & Willy

CARE GUIDE

Where you install your product depends on its material/s. We advise you use a qualified builder for installing The Acrylic Pavement Sign.


Wooden and Steel Products: We recommend using these products inside or under a shelter where they are protected from any exposure to rain or water.

Aluminum Products: These products are non-corrosive and suitable for use outside.

Chalk Products: You should use traditional dry chalk. We don't recommend using liquid chalk pens on our products.


Transportable Outdoor Signage: If there is exposure to wind, we recommend bringing signage inside to protect it from the extremes. We offer Sandbags to help support your product in moderate wind conditions.

COMPONENTS



..... 1 x Acrylic Pavement Sign


1



Begin setting up your Acrylic Pavement Sign by deciding what decal you would like to apply to the faces.


We recommend getting your local sign-writer to supply you with vinyl stickers for more permanent items like branding or opening hours.

2



Once you have your messages sorted, find a good spot outside your space to stand your Acrylic Pavement Sign and you're away!


3



This product also comes with a stabilising bracket. This bracket can be useful if you're in a windy area or need more structure in your sign.

On the bottom of the Acrylic Pavement Sign, there are three rubber feet on each foot. If you plan to install the bracket, the middle one needs to be unscrewed on each side.

4



Remove the rubber foot from the nut and bolt and place the bracket to the middle fixing points of the sign using the nut and bolt from the rubber foot.

Note: If you find that it needs more weight to be solid in the wind, place a heavy item like a Sand Bag on the bracket. We sell these separately.

DISCLAIMER

George & Willy products have a lifetime warranty.
This only covers faulty workmanship and hardware.
Not the electronics.

It does not cover normal wear and tear, accidents, or misuse of the product. If the defect was caused by a manufacturing fault, the faulty product will be replaced free of charge. If the original product is no longer in production, it will be replaced with the most similar product.

Please keep all parts out of reach of small children as they may pose a choking risk.

CONTACT US



@georgeandwilly



www.pinterest.com/georgeandwilly/



sales@georgeandwilly.com



www.georgeandwilly.com

THANK YOU

Don't forget to tag us on Instagram @georgeandwilly

For 10% off your next purchase, use the discount code:

WITHTHANKS