

GEORGE & WILLY®

HANGING MENU BOARD

The Hanging Menu Board is a simple and functional magnetic display board for your cafe, gallery, or business, easily reversible so you can swap between two menus or messages.

Signs are provided blank and made from powder-coated steel and aluminum with anodized aluminum brass hooks.

We recommend branding the Hanging Menu Board with our magnet letter packs or using vinyl decals that your local signwriters will be well equipped to make.

Thank you for your purchase,

George & Willy

CARE GUIDE

Where you install your product depends on its material/s.

Wooden and Steel Products: We recommend using these products inside or under a shelter where they are protected from any exposure to rain or water.

Aluminum Products: These products are non-corrosive and suitable for use outside.

Chalk Products: You should use traditional dry chalk. We don't recommend using liquid chalk pens on our products.

Transportable Outdoor Signage: If there is exposure to wind, we recommend bringing signage inside to protect it from the extremes. We offer Sandbags to help support your product in moderate wind conditions.

COMPONENTS



.....1 x Display Board



.....1 x Wall Mount



.....1 x Wall Stop



.....2 x Brass Hooks



.....2 x Black Hooks



.....12 x Wall Screws



.....2 x Bolts

1



If you want a vinyl application, we recommend sorting this first. We recommend contacting your local signwriter who will be able to apply your branding/message to the sign.


2



Measure your selected wall space and mark it with a pencil. We recommend using a level to ensure it is aligned. If you are mounting onto drywall, the Hanging Menu Board should be fixed into a wooden stud.

Note: There is a threaded hole in the 'hooks' groove. This side should face upwards.


3



Optional: If your Hanging Menu Board is placed in an environment subject to wind, you can use the wall stop to prevent the board from swinging. This magnet attaches to the wall and helps stabilize the board.

To install the wall stop, measure 250mm from the edge of the Mounting Bar and 700mm down to find the mounting position.


4



You have the option of brass hooks and black hooks, pick your color preference and place them in the hook grooves on the mounting bar.

Optional: If you would like to stop the hooks from swinging, gently fasten the 2 smaller bolts in through the top, or leave them free to swing.

5



The Hanging Menu Board is now good to go!

DISCLAIMER

George & Willy products have a lifetime warranty. This covers faulty workmanship and/or materials when the product is used in normal, domestic, or commercial conditions and following the care and use instructions provided.

It does not cover normal wear and tear, accidents, or misuse of the product. We recommend using a qualified builder to complete the installation to reduce the risk of damage or injury. If the defect was caused by a manufacturing fault, the faulty product will be replaced free of charge. If the original product is no longer in production, it will be replaced with the most similar product.

Please keep all parts out of reach of small children as they may pose a choking risk.

CONTACT US



@georgeandwilly



www.pinterest.com/georgeandwilly/



sales@georgeandwilly.com



www.georgeandwilly.com