GEORGE & WILLY®

MEDIUM ROUND SIGN

An upscaled version of our classic Round Sign, the Medium Round Sign boasts a whopping 23"/60cm of signage real estate to get your business noticed.

Constructed from aluminum, the Medium Round Sign stands up to the elements without weathering.

Signs are provided blank and made from powder-coated aluminum.

Thank you for your purchase,

George & Willy

CARE GUIDE

Where you install your product depends on its material/s.


Wooden and Steel Products: We recommend using these products inside or under a shelter where they are protected from any exposure to rain or water.

Aluminum Products: These products are non-corrosive and suitable for use outside.

Chalk Products: You should use traditional dry chalk. We don't recommend using liquid chalk pens on our products.

Transportable Outdoor Signage: If there is exposure to wind, we recommend bringing signage inside to protect it from the extremes. We offer Sandbags to help support your product in moderate wind conditions.

COMPONENTS




5 x Concrete Screws




Your Medium Round Sign comes blank and ready for your display to be applied. We recommend a local signwriter doing this for you.

Option 1 - Vinyl Sticker. Get your logo/details printed on a vinyl sticker at a local signwriter and apply it straight onto the sign.


Option 2 - Painted. A more traditional yet classic approach, have your display handpainted onto the Medium aRound Sign.



Select a space to install your Medium Round Sign, somewhere unobtrusive and highly visible. We recommend fixing the Medium Round Sign into studs or a solid wall. Insert the first screw using either the concrete or wood screws provided depending on your installation surface.



Using a level, position the sign so it is perfectly vertical. Fasten the remaining screws to ensure the Medium Round Sign is securely fixed to the wall.



You are all done! Your sign should be securely installed and on display for people to see.

DISCLAIMER

George & Willy products have a lifetime warranty. This covers faulty workmanship and/or materials when the product is used in normal, domestic, or commercial conditions and following the care and use instructions provided.

It does not cover normal wear and tear, accidents, or misuse of the product. If the defect was caused by a manufacturing fault, the faulty product will be replaced free of charge. If the original product is no longer in production, it will be replaced with the most similar product.

Please keep all parts out of reach of small children as they may pose a choking risk.

CONTACT US



@georgeandwilly



www.pinterest.com/georgeandwilly/



sales@georgeandwilly.com



www.georgeandwilly.com