

GEORGE & WILLY®

OPENING HOURS SIGN

We designed the Opening Hours Sign to displaying store hours, but it can offer so much more. You can use it as a menu, displaying specials, or even writing messages.

You can use it in multiple ways as well, whether it's hung in your window, on your benchtop, or mounted to your wall.

Thank you for your purchase,

George & Willy

CARE GUIDE

Where you install your product depends on its material/s.

Wooden and Steel Products: We recommend using these products inside or under a shelter where they are protected from any exposure to rain or water.

Aluminum Products: These products are non-corrosive and suitable for use outside.

Chalk Products: You should use traditional dry chalk. We don't recommend using liquid chalk pens on our products.

Transportable Outdoor Signage: If there is exposure to wind, we recommend bringing signage inside to protect it from the extremes. We offer Sandbags to help support your product in moderate wind conditions.

COMPONENTS



.....1 x Magnetic Board



.....1 x Leather Strap



.....1 x Magnetic Letter Set



.....1 x Wooden Base



.....2 x Wall Hooks



.....1 x Sticker



.....2 x Wall Screws




.....2 x Board to Base Screws

1

HOURS		
MON	09:00	06:30
TUE	09:00	06:30
WED	09:00	06:30
THU	09:00	06:30
FRI	09:00	06:30
SAT	10:00	04:00
SUN	CLOSED	

However you end up using your Opening Hours Sign, we recommend the first thing you do is apply your magnets. The sections on the board are designed so you can fit two rows of small magnet letters or one row of large.

2



Hanging



Table Mounted



Wall Mounted


The Opening Hours Sign can be used in three different configurations depending on your needs.

To install the Hanging Configuration, continue to step three.

To install the Table Mounted Configuration, skip to step five.


To install the Wall Mounted Configuration, skip to step six.

3




Hanging Configuration: Fit the board to base screw up through the leather strap and the large holes on the board. Using a washer between the nut and the board, tighten the nut. Do this on both sides. It is now ready to be hung.

4




Hanging Configuration (continued): Apply one Wall Hook to your window. Make sure you clean the window before applying the hook. Simply hang the board by placing the leather strap on the hook. We have included 2 hooks so if you want to reposition your sign, you easily can. Apply the sticker on the exterior of the glass to hide the backside of the hook's adhesive backing.

5



Tabletop Configuration: Fit the board to base screws up through the wooden base and the large holes on the board. Using a washer between the nut and the board, tighten the nut. Do this on both sides. It is now ready to be used.

6



Wall Mounted Configuration: Use the counter sunk screws to fix the base to the wall in your desired location. Hook the board over top of the base with the holes pointing up. Screw the small dome screws through the small holes on the board and into the base. The Opening Hours Sign is now fixed to the wall.

DISCLAIMER

George & Willy products have a lifetime warranty. This covers faulty workmanship and/or materials when the product is used in normal, domestic, or commercial conditions and following the care and use instructions provided.

It does not cover normal wear and tear, accidents, or misuse of the product. We recommend using a qualified builder to complete the installation to reduce the risk of damage or injury. If the defect was caused by a manufacturing fault, the faulty product will be replaced free of charge. If the original product is no longer in production, it will be replaced with the most similar product.

Please keep all parts out of reach of small children as they may pose a choking risk.

CONTACT US



@georgeandwilly



www.pinterest.com/georgeandwilly/



sales@georgeandwilly.com



www.georgeandwilly.com