GEORGE & WILLY®

SQUARE SIGN

Easily mounted to wood, brick, or concrete, The Square Sign was designed to make your business stand out on the sidewalk.

Crafted with powder-coated aluminum, the Square Sign is resistant to rust and weathering, making it perfect for exterior spaces.

Signs are provided blank and made from powder-coated aluminum. We recommend branding using vinyl decals that your local signwriters will be well equipped to make.

Thank you for your purchase,

George & Willy

CARE GUIDE

Where you install your product depends on its material/s.


Wooden and Steel Products: We recommend using these products inside or under a shelter where they are protected from any exposure to rain or water.

Aluminum Products: These products are non-corrosive and suitable for use outside.


Chalk Products: You should use traditional dry chalk. We don't recommend using liquid chalk pens on our products.

Transportable Outdoor Signage: If there is exposure to wind, we recommend bringing signage inside to protect it from the extremes. We offer Sandbags to help support your product in moderate wind conditions.


COMPONENTS	
	1 x Wall Bracket
	1 x Face Panel
[=======	4 x Concrete Screws
	6 x Bolts
D-33330-	4 x Wood/Drywall Screws
<u> </u>	




We recommend using a local signwriter to brand or decorate the Square Sign.



We suggest using a qualified builder when installing the Square Sign. Start by selecting the space to install your Square Sign. Place the bracket on the wall. Use a level to ensure the bracket sits perfectly vertically. Use a pencil to mark where the 4 x holes will be drilled.




Once the holes have been drilled and depending on what wall surface you have chosen (wood/concrete/brick), use the 4 screws provided to fix the bracket to the wall. We have supplied 4 x stand offs, these are for easier use with uneven wall surfaces and to give the sign a negative detail against the wall. We recommend using them.



4

Fasten the 6 x bolts in from the top to fix the face panel onto the wall bracket. These should be fastened by hand. Note: Avoid over tightening the bolts.



Your Square Sign is now mounted and good to go!

DISCLAIMER

George & Willy products have a lifetime warranty. This covers faulty workmanship and/or materials when the product is used in normal, domestic, or commercial conditions and following the care and use instructions provided.

It does not cover normal wear and tear, accidents, or misuse of the product. If the defect was caused by a manufacturing fault, the faulty product will be replaced free of charge. If the original product is no longer in production, it will be replaced with the most similar product.

Please keep all parts out of reach of small children as they may pose a choking risk.

CONTACT US



@georgeandwilly



www.pinterest.com/georgeandwilly/



sales@georgeandwilly.com



www.georgeandwilly.com