

GEORGE & WILLY[®]

SQUARE WALL SIGN

The Square Wall Sign is a simple and stylish wall-mounted sign for your store, cafe, gallery, or boutique. This outdoor business sign is easily mounted to wood, brick, and concrete, designed to make your storefront stand out.

Made from aluminum with a high-quality powder coat finish, the flat square store sign is easily customizable and perfect for displaying your logo or a permanent message with the use of decal signwriting.

Thank you for your purchase,

George & Willy

CARE GUIDE

Where you install your product depends on its material/s.


Wooden and Steel Products: We recommend using these products inside or under a shelter where they are protected from any exposure to rain or water.

Aluminum Products: These products are non-corrosive and suitable for use outside.


Chalk Products: You should use traditional dry chalk. We don't recommend using liquid chalk pens on our products.

Transportable Outdoor Signage: If there is exposure to wind, we recommend bringing signage inside to protect it from the extremes. We offer Sandbags to help support your product in moderate wind conditions.

COMPONENTS



.....1 x Sign Face



.....1 x Wall Bracket



.....4 x Bracket Bolts



.....4 x Concrete Screws




.....4 x Wood Screws

1



Your Square Wall Sign comes blank and ready to have your branding or message applied to it.

2



Select a space to install your sign. The sign should be fixed into studs or a solid wall. Depending on the wall, pick between the wood screws or the concrete screws. Make sure the bracket is in portrait orientation. Use a level to get the bracket straight and fasten the screws with a drill. Put a screw in each of the four holes.

3



Slide the Sign inside the Wall Bracket. Using the long magnetic driver screwdriver supplied, fix the Bracket Bolts into the Wall Bracket to secure the Sign Face. Start with the bottom bolts as this will hold the sign in place while you finish off the top bolts. It is best to have two people complete this step.

4



Your Square Wall Sign is now ready to display your messaging/logo.

DISCLAIMER

George & Willy products have a lifetime warranty. This covers faulty workmanship and/or materials when the product is used in normal, domestic, or commercial conditions and following the care and use instructions provided.

It does not cover normal wear and tear, accidents, or misuse of the product. If the defect was caused by a manufacturing fault, the faulty product will be replaced free of charge. If the original product is no longer in production, it will be replaced with the most similar product.

Please keep all parts out of reach of small children as they may pose a choking risk.

CONTACT US



@georgeandwilly



www.pinterest.com/georgeandwilly/



sales@georgeandwilly.com



www.georgeandwilly.com