

GEORGE & WILLY®

STAMPED CARD MENU

A true mix of classical lettering techniques paired with a minimalist design intention, the Stamped Card Menu is a creative way to share your message.

Designed for your menu, an important message, or inspirational quote, the Stamped Card Menu is crafted from aluminium with an anodized coating, and uses a system of cards and stamps to make changing your display easy.

Thank you for your purchase,

George & Willy

CARE GUIDE

Where you install your product depends on its material/s.

Wooden and Steel Products: We recommend using these products inside or under a shelter where they are protected from any exposure to rain or water.

Aluminum Products: These products are non-corrosive and suitable for use outside.

Chalk Products: You should use traditional dry chalk. We don't recommend using liquid chalk pens on our products.

Transportable Outdoor Signage: If there is exposure to wind, we recommend bringing signage inside to protect it from the extremes. We offer Sandbags to help support your product in moderate wind conditions.

COMPONENTS

 12 x Rails

 50 x Stamp Cards

 1 x Stencil Jig

 1 x Ink Pad

 1 x Stamp Set - Large Letters

 1 x Stamp Set - Small Letters

 26 x Wood/Drywall Screws

1

Vertical




Horizontal



Choose a configuration for your Stamped Card Menu. Depending on your space, the rails can be installed below one another, or side-by-side. To correctly install your board, we recommend using a qualified builder.

2




Select a wall space to install the Stamped Card Menu. The rails should be fixed into studs or a solid wall. Insert the first screw in the left hole.

3



Using a level, position the rail so it is perfectly horizontal. Fasten the second and third screws and ensure the rail is securely fixed to the wall.

4



Place one of the paper cards in the first rail. Using this as a guide, position and fix the second rail onto the wall. Continue this method for the remaining rails. Make sure the rails are nice and tight on the spacer to ensure the rails are parallel.

5

WELCOME


PLACE YOUR ORDER HERE



Choose your menu layout and stamp size and proceed to stamp your menu, messages, or quotes onto the pieces of card. Press the stamp evenly onto the ink pad and then again onto the card.

Tip: If you avoid rolling the stamp on its edges, you will get a clean and tidy transfer of ink onto the card.

6



Slide the card along the rail slot to create your display.

DISCLAIMER

George and Willy products have a lifetime warranty. This covers faulty workmanship and/or materials when the product is used in normal, domestic, or commercial conditions and following the care and use instructions provided.

It does not cover normal wear and tear, accidents, or misuse of the product. If the defect was caused by a manufacturing fault, the faulty product will be replaced free of charge. If the original product is no longer in production, it will be replaced with the most similar product.

Please keep all parts out of reach of small children as they may pose a choking risk.

CONTACT US



@georgeandwilly



www.pinterest.com/georgeandwilly/



sales@georgeandwilly.com



www.georgeandwilly.com