

GEORGE & WILLY®

BAR MENU

The Bar Menu is a bold take on displaying your menu or message, a great addition to your store, studio, or cafe.

The steel panels are left raw and coated in a matte clear coat to protect them from the elements. We recommend using our magnet letter packs for displaying your messages or using vinyl decals that your local signwriters will be well equipped to make.

Thank you for your purchase,

George & Willy

CARE GUIDE

Where you install your product depends on its material/s.

Wooden and Steel Products: We recommend using these products inside or under a shelter where they are protected from any exposure to rain or water.

Aluminum Products: These products are non-corrosive and suitable for use outside.

Chalk Products: You should use traditional dry chalk. We don't recommend using liquid chalk pens on our products.

Transportable Outdoor Signage: If there is exposure to wind, we recommend bringing signage inside to protect it from the extremes. We offer Sandbags to help support your product in moderate wind conditions.

COMPONENTS



.....4 x Wooden Rails




.....10 x Steel Rail

.....1 x Block Magnet Letter Pack




.....12 x Wall Screws

1



Vertically



Horizontally

Start by considering your layout - you can stack your Bar Menu's wooden rails to ways (pictured). Measure the width and height on your wall to decide the best position. You should use a qualified builder to install the Bar Menu.


2



After you have finished measuring, fix the first wooden rail to the wall. Start with the top screw, ensuring the rail is perfectly vertical with a level.

Note: To correctly orientate the rails, the slots should be angled downwards (for the steel rails to slot into), and the slot nearest the end must be at the top.

3



You can choose your distance between wooden rails depending on your personal preference. We positioned them 650mm apart (center to center) so that the steel rails had 150mm of overhang at each end.


After measuring the distance, fix the second wooden rail in place again starting with the top screw, and using the level, fix the bottom screw in place so that it is perfectly level.

4



Depending on your chosen orientation (side-by-side or vertically stacked) you will need to follow the same process with the third and fourth wooden rail. Remember to level the rails and check correct orientation.

5



Your Bar Menu is now good to go! Decorate and display your menu with one of our magnetic letter packs.

6



Note: The Bar Menu is designed to be indoors. If you want to use this menu somewhere outside or in a windy setting, it may be beneficial to use an adhesive product to fix the steel Rail Boards firmly into the slots.

DISCLAIMER

George & Willy products have a lifetime warranty. This covers faulty workmanship and/or materials when the product is used in normal, domestic, or commercial conditions and following the care and use instructions provided.

It does not cover normal wear and tear, accidents, or misuse of the product. If the defect was caused by a manufacturing fault, the faulty product will be replaced free of charge. If the original product is no longer in production, it will be replaced with the most similar product.

Please keep all parts out of reach of small children as they may pose a choking risk.

CONTACT US



@georgeandwilly



www.pinterest.com/georgeandwilly/



sales@georgeandwilly.com



www.georgeandwilly.com