


USE AND CARE GUIDE

BEDFORD FARMHOUSE HIGH DINING CHAIR



Questions, problems, missing parts?

Before returning to the store, call Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

THANK YOU

We appreciate the trust and confidence you have placed in StyleWell through the purchase of this chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing StyleWell!

Table of Contents

Table of Contents	Pre-Assembly	. 3
	Planning Assembly	
Important Safety Instructions	Hardware Included	
Warranty	Package Contents	. 3
What is Covered	Assembly	. 4
What is not Covered	Care and Cleaning	. 5

Important Safety Instructions

SAVE THESE INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND DOES NOT APPLY TO COMMERCIAL USE

1 YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame and the fabric to be free of manufacturing defects to the original purchaser for one years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact the Customer Service Team at 1-877-527-0313 or visit www.homedepot.com.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Verify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.



NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6*25 mm Bolt	4
BB	Allen Wrench	1

PACKAGE CONTENTS



Part	Description	Quantity
Α	Chair frame	1
В	Chair support bar	1
С	Seat cushion	1


Assembly

1 Attaching the support bar

- Carefully place the chair upside down on a soft, flat, and non-abrasive surface.
- □ Attach the chair support bar (B) to the chair frame (A) by using the bolts (AA).
- □ Tighten all bolts with the Allen Wrench (BB).




NOTE: Please ensure all M6 bolts are aligned and assembled correctly. Fully tighten the bolts.



2 Adding the seat cushion

- $\ \ \square$ Turn the chair over.



Care and Cleaning

- □ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- □ Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.

5 HOMEDEPOT.COM

StyleWell

Questions, problems, missing parts? Before returning to the store, call StyleWell Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

Retain this manual for future use.



USE AND CARE GUIDE

BEDFORD FARMHOUSE HIGH DINING TABLE



Questions, problems, missing parts?

Before returning to the store, call Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

THANK YOU

We appreciate the trust and confidence you have placed in StyleWell through the purchase of this table. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing StyleWell!

Table of Contents

Table of Contents	Pre-Assembly
Important Safety Instructions2	Planning Assembly
Warranty	Package Contents
What is covered	Assembly
What is not covered	Care and Cleaning!

Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND DOES NOT APPLY TO COMMERCIAL USE

1 YEAR FRAME LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame and the fabric to be free of manufacturing defects to the original purchaser for one years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact the Customer Service Team at 1-877-527-0313 or visit www.homedepot.com.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Verify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.



NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.












Part	Description	Quantity
AA	M6*35mm Bolt	8
BB	M6*25mm Bolt	10
CC	Allen Wrench	1

PACKAGE CONTENTS







Part	Description	Quantity
Α	Table top	1
В	Table legs	2
С	Support bars	2
D	Leg connector	1


Assembly

Attaching the table legs

- Carefully place the table top (A) on a soft, flat, and non-abrasive surface.
- Attach the table legs (B) to the table top (A) by using M6x35mm bolts (AA).




Note: Loosely tighten all the bolts by using the Allen Wrench (CC) until end of step $\bf 3$.




2 Attaching the support bars

□ Attach the support bars (C) to the table top (A) and table legs (B) by using M6x25mm bolts (BB).



3 Attaching the leg connector

- □ Attach the leg connector (D) between the two table legs (B) by using M6x25mm bolts (BB).
- □ Once all of the bolts are in place, fully tighten all the bolts.



4 Positioning the table

- □ Turn the table over and set it down on its legs.
- □ The table is now ready for use.



Care and Cleaning

- □ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- □ Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.

5 HOMEDEPOT.COM

StyleWell

Questions,problems, missing parts? Before returning to the store, call StyleWell Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

Retain this manual for future use.