

Assembly Manual

Halstead 4pc Seating set Model Number: GC-11244-4PC

Customer Assistance (spare/replacement parts): Service Number: 1-888-691-2824 or Service Email address: customerservice@coronadocasuals.com



THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Questions or Comments? We would love to hear about your Member's Mark experience! Visit us at:

samsclub.com/membersmarkhelp



Important Safety Information

- Please read all instructions carefully before assembling this furniture.
- For your safety, assembly by two or more adults is strongly recommended.
- Use only vendor-supplied hardware to assemble this item. Using unauthorized hardware could jeopardize the structural integrity of the item.
- Hardware may loosen overtime. Periodically check that all connections are tight.

Before Assembly

- Remove all parts and hardware from the box. Place all items on a carpeted or scratch-free work surface, as this will avoid damaging parts during assembly.
- The shipping box provides an ideal work surface.
- To avoid accidentally discarding small parts or hardware, do not dispose of any packaging or contents of the shipping carton until assembly is complete.
- Use the parts and hardware lists below to identify and separate each of the pieces included.
- The use of power tools for assembly is not recommended. Power tools can damage the hardware.
- **Note:** Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions may cause the bolts to misalign during assembly.

Care and Cleaning

• Dust often and use a vacuum cleaner crevice tool to clean seams. To maintain the woven appearance, gently clean soiled areas with a soft cloth dampened with a mild, water based detergent. Remove all lather and wipe with a clean damp cloth. Dry with another soft cloth by blotting the damp surface (do not rub).

Coffee Table

Components

A.....1

B......4



Hardware

(C)	(D)		(E)
Allen/Hex Bolt	M6 Washer		M6 Allen Wrench
M6x20mm	Qty: 12	0	Qty: 1
Qty: 12			

Step 1



Carefully place table top (A) upside down a soft, flat and non-abrasive surface. Attach the table legs(B) to table top (A) with bolts(C) and Washer(D) by using M6 Allen Wrench(E).

Tighten all the bolts with M6 Allen Wrench(E).

Step 2



Carefully turn the coffee table over.

The coffee table is ready for your enjoyment.

If the chair, sofa and table is uneven, you can adjust the feet to make it even.

Furniture Cover

Components

- F.....2 F.....2
- G....Furniture cover for lounge chair....2
- H....Seat cushion for Lounge chair.....2
- I.....Back cushion for Lounge chair.....2
- J....Lumbar for Lounge chair.....2
- K...Sofa.....1
- L....Furniture cover for sofa.....1

- M.....Seat cushion for sofa......2
- N.....Back cushion for sofa.....2
- O.....Toss pillow 1 for sofa.....2
- P.....Toss pillow 2 for sofa.....2
- Q....Cofeee table.....1
- R....Furniture cover for coffee table...1

Furniture Cover







Furniture Cover



For maximum protection, use Heavy Duty Furniture Cover (G&L&R). Fasten adjustable cord lock to secure the cover from wind and snug fit.