
HAMPTON BAY

USE AND CARE GUIDE

HIGHGARDEN PADDED SLING CHAISE LOUNGE



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Table of Contents

Table of Contents2	Pre-Assembly3
Important Safety Instructions	Planning Assembly
important Safety instructions2	Hardware Included3
Warranty	Package Contents3
What is Covered2	Assembly
What is not Covered2	Care and Cleaning5

Important Safety Instructions

SAVE THESE INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND THIS WARRANTY DOES NOT APPLY TO COMMERCIAL USE

2 YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame and the fabric to be free of manufacturing defects to the original purchaser for two years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team at 1-855-HD-HAMPTON or visit www.hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Verify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-ab rasive surface to avoid scratching.



NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.














Part	Description	Quantity
AA	M6 x 20 mm combination bolt	8
BB	M6 x 40 mm combination bolt	4
CC	Plastic washer	2
DD	M6 Allen wrench	1

PACKAGE CONTENTS



Part	Description	Quantity
Α	Seat panel	1
В	Left arm	1
С	Right arm	1
D	Connect bar	1
Е	Back panel	1


Assembly

Attaching the arms and connect bar

- Attach the left arm (B) and right arm (C) to the seat panel (A) with M6 x 20 bolts (AA) and M6 x 35 bolts (BB).
- □ Attach the connect bar (D) and right arm (C) and left arm (B) with M6 x 20 bolts (AA). Tighten all bolts with M6 wrench (DD).



NOTE: Please ensure all bolts are aligned and assembled correctly. Fully tighten all the bolts.




2 Attaching the back panel

□ Attach the back panel (E) to the seat panel (A) with M6 x 40 bolts (BB) and plastic washers (CC).




NOTE: Please ensure all bolts are aligned and assembled correctly. Fully tighten all the bolts with M6 Allen wrench (DD).



3 Positioning the chaise

 $\hfill\Box$ Turn the chaise lounge over. The chaise is now ready for use.



Care and Cleaning

- □ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.

HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.