

USE AND CARE GUIDE

JAMES CREEK LOUNGE CHAIR



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.CA

THANK YOU

Table of Contents

Table of Contents	Pre-Assembly
Important Safety Instructions2	Planning Assembly
Warranty	Package Contents
What is covered	Assembly
What is not covered	Care and Cleaning!

Important Safety Instructions

SAVE THESE INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND THIS WARRANTY DOES NOT APPLY TO COMMERCIAL USE

2 YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for five years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.hamptonbay.ca.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.




NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6*45 mm Hex bolt	4
BB	M6*40 mm Hex bolt	4
CC	M6 Washer	8
DD	M6 Hex bolt cap	8
EE	M6 Hex Wrench	1

PACKAGE CONTENTS



Part	Description	Quantity
Α	Left arm panel	1
В	Right arm panel	1
С	Seat panel	1
D	Chair back	1
E	Seat cushion	1
F	Back cushion	1


Assembly

Attaching the arm panel

- With the assistance of another person, insert the chair back (D) into the left arm panel (A) and right arm panel (B) and secure together using M6x45 hex bolts (AA) and M6 washers (CC).
- □ Tighten all M6x45 Hex bolts (AA) with the M6 wrench (EE).
- Cover the bolt heads with caps (DD).




NOTE: Please ensure all M6 bolts are aligned and assembled correctly. Fully tighten the bolts.




2 Attaching the seat panel and back panel

- Attach the seat panel (C) to chair frame and chair back (D) using M6x40 hex bolts (BB) and M6x40 washers (CC).
- □ Tighten all M6x40 Hex bolts (BB) with the M6 wrench (EE).
- Cover the bolt heads with caps (DD).



3 Adding the cushions

- Place the seat cushion (E) and back cushion (F) on the lounge chair.
- The chair is now ready for use.



Care and Cleaning

- □ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.

5

- □ Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON


HAMPTONBAY.CA

Retain this manual for future use.



USE AND CARE GUIDE

JAMES CREEK OTTOMAN



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.CA

THANK YOU

Table of Contents

Table of Contents	Pre-Assembly	3
	Planning Assembly	
Important Safety Instructions	Hardware Included	
Warranty	Package Contents	3
What is covered	Assembly	4
What is not covered	Care and Cleaning	5

Important Safety Instructions

SAVE THESE INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND THIS WARRANTY DOES NOT APPLY TO COMMERCIAL USE

2 YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for five years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.hamptonbay.ca.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.




NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6*25 mm Hex bolt	4
BB	M6 Washer	4
CC	M6 Hex bolt cap	4
DD	M6 Hex Wrench	1

PACKAGE CONTENTS



Part	Description	Quantity
Α	Seat panel	1
В	Side panel	1
С	Seat cushion	1


Assembly

Attaching the panels

- Attach the seat panel (A) to the side panel (B) using the M6 hex bolts (AA) and washers (BB).
- □ Cover the bolt heads with caps (CC).




NOTE: Please ensure the bolts are assembled correctly and use the M6 wrench (DD) to tighten.



2 Adding the cushion

□ Place the seat cushion (C) on the ottoman.



Care and Cleaning

- □ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.

5

- □ Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON


HAMPTONBAY.CA

Retain this manual for future use.



USE AND CARE GUIDE

JAMES CREEK SIDE TABLE



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.CA

THANK YOU

Table of Contents

Table of Contents	Pre-Assembly3
Important Safety Instructions	Planning Assembly
Important Safety Instructions2	Hardware Included3
Warranty	Package Contents
What is covered	Assembly
What is not covered	Care and Cleaning5

Important Safety Instructions

SAVE THESE INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND THIS WARRANTY DOES NOT APPLY TO COMMERCIAL USE

2 YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for five years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.hamptonbay.ca.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.




NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6*20 mm Hex bolt	8
BB	M6*15 mm Hex bolt	4
CC	M6 Washer	12
DD	M6 Hex bolt cap	12
EE	M6 Hex Wrench	1

PACKAGE CONTENTS



Part	Description	Quantity
Α	Table top	1
В	Table leg	4
С	Leg connector	1

3


Assembly

Attaching the table legs



NOTE: Please ensure the bolts are assembled correctly and use the M6 wrench (EE) to tighten.

- □ Attach the four legs (B) to the leg connector (C) using the M6x15 hex bolts (BB) and washers (CC).
- Cover the bolt heads with caps (DD).




2 Attaching the table top

- □ Place the table top (A) on a soft, flat non-abrasive surface.
- Attach the table legs (B) to the table top (A) with the M6x20 hex bolts (AA) and washers (CC). Tighten all bolts and cover the heads with caps (DD).




NOTE: Please ensure the bolts are assembled correctly and use the M6 wrench (EE) to tighten.



3 Positioning the table

- □ Turn the table over and set it down on its legs.
- □ The table is now ready for use.



Care and Cleaning

- □ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- □ Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.CA

Retain this manual for future use.