
1004 307 687 1004 307 694 1004 298 610 Model# S43-0001A A43-0001A

HAMPTON BAY

USE AND CARE GUIDE

RIVERBROOK PADDED SLING CHAISE LOUNGE



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents2	Pre-Assembly3
Important Safety Instructions	Planning Assembly
Important Safety Instructions2	Hardware Included3
Warranty	Package Contents 3
What is covered	Assembly
What is not covered	Care and Cleaning5

Important Safety Instructions

SAVE THESE INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND THIS WARRANTY DOES NOT APPLY TO COMMERCIAL USE

3 YEAR FRAME AND 2 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.



NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.







BB



CC



Part	Description	Quantity
AA	M6*20 mm bolt	8
BB	M6*40 mm bolt	4
CC	M6 Plastic washer	2
DD	M6 Wrench	1

PACKAGE CONTENTS












Part	Description	Quantity
Α	Seat panel	1
В	Right arm	1
С	Left arm	1
D	Connect bar	1
Е	Back panel	1

Assembly


Attaching the arms and connect bar

- Attach the right arm (B) and left arm (C) to the seat panel (A) with M6x20 bolts (AA) and M6x40 bolts (BB).
- Attach the connect bar (D) to the right arm (B) and left arm (C) with the M6x20 bolts (AA). Tighten all bolts with M6 wrench (DD).




2 Attaching the back panel

□ Attach the backpanel (E) to the seat panel (A) with M6x40 bolt (BB) and M6 plastic washers (CC).



3 Positioning the chaise

□ Turn the chaise over and the chaise is now ready for use.



Care and Cleaning

- □ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.

HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.