



VAPOR AUTHORITY® www.VaporAuthority.com

aspire®

User manual for K4 Quick Start kit

Instructions

1. Pressing the fire button five times within two seconds will turn on and off the K4 battery. The fire button will flash blue and orange three times to indicate off or on.
2. When the K4 is in use the light on the button will indicate your K4's current charge. When the K4's current charge capacity is above 3.8 volts the fire button will be blue and orange. When the charge is between 3.8 and 3.5 volts the button will be blue only. When the charge drops below 3.5 volts the light will then become orange to remind you that it is time to charge your K4.

Protective Features

1. Automatic cutoff: After 10 seconds of use the device will cease firing and the LED light will flash both blue and orange ten times.
2. Short circuit protection: If the K4 detects a short circuit the device will immediately cease firing and the light will flash both blue and orange three times.
3. Low voltage protection: When the K4's charge drops to 3.2 volts the LED will flash orange fifteen times and the device will stop functioning.
4. Overcharge protection: When the battery has fully charged to 4.2 volts the K4 will automatically stop charging.

Charging Instructions: While charging the K4's LED will shine red, when the voltage reaches 4.2 the LED on the bottom will turn green to indicate that your K4 is fully charged.

Specifications: 1. K4 tank capacity: 3.5ml 2. K4 atomizer: Kanthal Clapton 0.27 ohm, 40-55 Watts(preinstalled) 3. K4 battery capacity: 2000 mah 4. Bypass output