WAPOR AUTHORITY, www.VaporAuthority.com

Thank you for choosing Eleaf products! Please read this manual carefully before use so as to use correctly. If you require additional information or have questions about the product or its use, please consult your local agents, or visit our website at www.eleafworld.com.

Product Introduction

iJust S, a new starter kit, has a larger diameter of 24.5mm and a higher battery capacity of 3000mAh compared to previous iJust series kits. All parts of the iJust S atomizer can be detached and reassembled, bringing much more convenience in cleaning and maintenance. The e-liquid can be refilled by removing the top cap only with ease. When used with new ECL 0.18ohm Head, the iJust S will bring you a different vaping experience with nice flavor.

How to Use?

1 | iJust S | English

Assembling:

1. First drip a few drops of e-liquid directly into the coil to make it fully saturated and screw the atomizer head onto the atomizer base tightly.

2. Then screw the atomizer tube onto the atomizer base.

3. Next screw off the top cap; slowly fill e-liquid into the atomizer along the glass tube and screw the top cap with mouthpiece back onto the atomizer tube tightly after filling. (Note: please don't overfill and don't fill e-liquid into the air pipe; please take several puffs without activating the atomizer and leave the atomizer sit for several minutes before first use.)





3 iJust S | English

occurs with the white button light flashing 3 times.

No Atomizer Protection: The white button light will flash slowly when the button is pressed down without atomizer connected.

Low-voltage Protection: When the voltage of the device is below 3.3V, the white button light will flash 40 times. At the same time, the device won't turn on.

Unlock the Low-voltage Protection: Charge the device till the voltage is above 3.7V. Then the low-voltage protection will be unlocked automatically. Battery Level Indication Function: The white button light will stay lit or flash slowly after a puff when the battery level is high. On the contrary, the light will flash

in frequency.

Battery Level	Light Condition
60%-100%	Stay lit
30%-59%	Slowly flashes
10%-29%	Moderately flashes
0-9%	Flashes in frequency

We are not responsible for any damages caused by human error. Legal warranty is iJust S | English

Warnings 1. Please keep out of reach of children. 2. This product is not recommended for use by young people, non-smokers, pregnant or breast-feeding women, or persons who are allergic/sensitive to nicotine. Contra-indication 1. Do not attempt to repair the product by yourself as damage or personal injury

3. Do not use this product for other purposes except only for vaping and don't

2. Do not leave the product in high temperature or damp conditions, otherwise it may be damaged.

swallow the e-liquid. Possible Adverse Effects

1. This product may be hazardous to health and contains nicotine which is

2. For people with adverse reaction after using this product, it is recommended to use the e-liquid with lower nicotine content or no nicotine.

English | iJust 5 | 6



Atomizer Head Air Pipe Glass Tube Mouthpiece Base

iJust S Battery Button iJust S Atomizer

4. Put the airflow control ring on the atomizer base and the airflow can be adjusted by rotating the silicone ring.

5. Finally screw the atomizer onto the battery and the iJust S is ready for use.

Power on/off: Press the button 5 times in quick succession within two seconds, the white button light will flash 5 times to show iJust S is powered on. In the same way, the device can be turned off.

Vaping: Long press the button to take a puff.

Charging: Charge the device by connecting it with wall adapter or computer via USB cable. The light will turn red when the device is charging and the light will go out when fully charged. It will take about 4 hours to get a full charge via 1A wall adapter.

applied.

Atomizer Protection: When vaping time exceeds 15 seconds, the device shuts off automatically with the white button light flashing 10 times. Short-circuit Protection: When the resistance is less than 0.15ohm, short-circuit

English | iJust S 2

English | iJust S 4