

#### Introduction:

TFV8 Big Baby is the enlarged version of Baby Beast—TFV8 Baby. It adopts new engines: V8 Baby-X4 Core, V8 Baby-T6 Core and V8 Baby RBA. Meanwhile, both 5ml bigger e-juice capacity and more vapors will let you enjoy pleasant vaping time. Innovation keeps changing the vaping experience!

#### Specifications:

Material: Stainless Steel      Size: 24.5x56mm  
Weight: 60g      Capacity: 5ml  
Thread: 510

#### The Kit Includes:

1 x TFV8 Big Baby Tank  
1 x V8 Baby-X4 Core (0.15Ω quadruple coils) (Pre-installed)  
1 x V8 Baby-T6 Core (0.20Ω sextuple coils)  
1 x V8 Baby RBA  
1 x Replacement Glass Tube for RBA  
1 x Replacement Glass Tube  
1 x 510 Drip Tip Adapter  
1 x User Manual  
Spare Parts

#### Components



#### How to fill with e-liquid:

1. Hold the tank with one hand, and use another one to press top cap and move it counterclockwise.



2. Add e-liquid through the slot, and pay attention not to drip in into the central airflow tube.



#### Control air input:

Rotate the bottom adjustable airflow system to control air input.



Close the cap carefully and firmly. Then let it stands for several minutes to get the organic cotton completely saturated.



#### Replace atomizer core:

Firstly, screw the drip tip and top cap off the tank; then screw the atomizer core off the base part, and replace with a new one.



#### How to build the RBA:

1. Before starting make sure your hands are clean.

2. Taking TFV8 Big Baby RBA apart.



3. Installing and positioning the pre-wrapped coil.

Place the coil between the posts and wrap the ends around the screws and tighten up, once all in place make sure the coil is fixed in the center and lined up with the air hole, and also make sure the coil is NOT touching the base.



4. Cutting the ends of wire off.

5. Cutting a strip of cotton and make sure it's not too much and not too less.

6. Inserting the cotton, and placing it in the middle.

7. Cutting the cotton at an angle and make sure it's not too short and not too long.



8. Wet the coil with your e-liquid and adjust the cotton.

**Warning:** Coils must be checked for resistance before they are fired on a device, and re-checked periodically to ensure the resistance remains the same.