


owerpod Air 10 User Manual



Safety Instructions

- Do not throw the Powerpod into fire or try to heat it. In such situations it might burn, explode or release toxic gas
- Do not connect the micro USB input and USB output ports with a single cable
- Do not try to open the Powerpod by yourself or break it.
- Do not put the Powerpod in water or make it wet.
- uo not use Powerpod if you notice it is leaking, heating itself, out of shape smelling or any other abnormal phenomenon.
- Do not use the Powerpod at higher temperature than 60 °C. The recommended ambient temperature is between 15 °C and 25 °C.

Storage and Mainterance

- If you will not use the Powerpod for а long time, please at least once a year fully charge it, then discharge it by some outer devices, then recharge it to half capacity and then keep it cool and dry place. in а
- It is recommended to perform a complete charging and discharging every 3 months so as to ensure the best status of the battery cells inside.

Support

For support please visit our website at www.powerpod.net or email us at support@powerpod.net