

powerpod


Air 20 Max

Portable Battery Pack
User Manual

Please read this manual carefully before using
the product and keep it safe.

Dear Customer:
Thank you for purchasing this product! Please read the "User Manual"
carefully before using this product and operate correctly according to the
instructions.

Product View:



Technical Parameters:


Model	Air 20 Max
Battery Type	Lithium ion
Battery capacity	2000mAh@3.7V
Battery energy	74Wh
Rated input	Micro USB DC 5-12V 18W QC Type-C DC 5-20V 45W PD
Rated output	USB 1 DC 5V/2A USB 2 DC 5-12V 18W QC Type-C DC 5-20V 45W PD
Operating temperature	0°C~45°C
Product Size	158(L)×73(W)×24(H)mm
Product Weight	480g

Package Contents:


Power bank ×1 Micro USB cable ×1
User Manual ×1 USB-C cable ×1

Instructions for use:


RECHARGE BEFORE FIRST USE




Charge Mobile Phones



Charge Digital Products



Charge laptop



Charge the battery pack itself by
an external AC power adapter

Charge the power bank:

Connect the Micro USB connector of Micro usb cable to the Power bank
input port. Connect the other end of the cable to computer or power
adapter USB Out.

When charging the power bank, the VA display will show the percentage
of battery remaining and input status sign.
When the charging is completed, please unplug the cable.

Use power bank to charge a digital device:

Connect the USB connector of Micro usb cable to the power bank output
port and the other end to digital device charging port, then it will begin
to charge automatically.

The VA display will show the percentage of remaining power, output
status sign, voltage and current.
When charging is complete, please unplug the cable.

When power bank is in stand by status, press On/Off switch to wake up
the power bank, the VA display will show the percentage of remaining
power and the last working status(In/Out).

Use power bank to charge a laptop:

The power bank can charge compatible laptops with USB-C input port.
Connect one end of USB-C cable to power bank USB-C port and the other
end to laptop USB-C input port, it will begin to charge the laptop
automatically.

The VA display will show the percentage of remaining power, output
status sign, voltage and current.
When charging is complete, please unplug the cable.

Precautions:

1. Before using, please note the instructions of the power bank to
ensure proper use.
2. For the first use, it is recommended that the power bank be fully
charged.
3. To charge the power bank, it is recommended to use formal brand
power adapter.
4. Use a power bank to charge other devices, please choose the
correct cable.
5. To charge other devices, if the power bank remaining battery is
low, please recharge it as soon as possible.
6. Please keep the power bank clean and dry, do not use chemicals,
soap, damp cloth to wipe the product.
7. Keep the power bank in a dry place away from moisture and
corrosive items.
8. After a long time of storage, please do several discharging and
charging cycles to ensure the best performance of the power bank.
9. This product is not a toy, please prohibit the use by children.
10. If you notice the power bank changes shape or some other
phenomena, please stop using it immediately.
11. If there is a leak of electrolyte, do not contact the skin or eyes
directly; if contact occurs, apply a large amount of water to rinse
the contact site and seek medical attention.
12. Please dispose the power bank carefully.

Warning:

Do not disassemble, impact, squeeze the power bank, do not place in
direct sunlight or throw the power bank into a fire.

Storage and Maintenance:

If you do not use the portable battery pack for a long period, please
follow the instructions below every 12 months to maintain its normal
functions:

First, fully charge the portable battery pack, then discharge the power by
an outer device. Finally, recharge it to half capacity, and store in a cool
and dry place.
It is recommended to do a complete charging and discharging every 3
months to ensure the best status of the battery cells inside.

Support:

Please email support@powerpod.net

Made in China

70mm

70mm

70mm

110mm

技术要求:
工艺: (CMYK) 四色印刷
尺寸: 110×70mm
材质: 100G书纸
颜色: 1C(白底黑字)
表面处理: 无
折页: 对折
公差: ±1mm