



2.4GHz Wireless Keyboard with Touchpad

USER MANUAL




Package Contents

- 1 x Wireless Keyboard
- 1 x 2.4GHz USB Receiver
- 1 x User Manual

Specification

Model No.	VILP019
Connected by	2.4G Wireless (with dongle)
Operating distance	< 10 m / 32.8 ft
Battery type	2*AAA (not included)
Power consumption	3.0V/10mA
Material	Galvanized(front) + ABS(back)
Dimensions	374.98*129.38*17.60mm
Net weight	435.6g

Indicator Light Description



- ① Fn lock indicator (Blue)
- ② Caps lock indicator (Green)
- ③ Power indicator (Green) / Low battery indicator (Green)
- ④ Power Switch (ON/OFF)

Package Contents

- Step 1. Insert 2 AAA batteries (Not included) .
- Step 2. Turn on the power switch to ON position.



Step3.Insert Dongle into a USB port on your Raspberry Pi or Computer, the keyboard should connect automatically (if the keyboard does not connect please follow step 4 below)















Step 4. Press ESC+Q for 2 seconds and the power indicator will blink green ,then insert 2.4G wireless receiver into the USB port of the Raspberry Pi /Computer, it will match automatically.

Note: After pairing for the first time, your device will connect to the keyboard automatically when the keyboard is switched on next time.


Language switching guide




- Samsung Android: Shift + Space
- Google Android: Ctrl + Space
- Windows: Win + Space








Keys and Functions

	Esc		Mute		Volume -
	Volume +		Previous track		Play / pause
	Next track		Brightness -		Brightness +
	Favorites		Switch App		Web browser
	Mouse right button		Back		




Package Contents

Key Icon	Function
 Fn+	Touchpad on/off

Gesture	Function
 one finger click	Mouse left button
 one finger slide	Move the cursor
 one finger hold click quickly and slide	Select and move

Gesture	Function
 <p>two fingers click</p>	<p>Mouse right button</p>
 <p>two fingers move vertically</p>	<p>Roll vertically</p>
 <p>two fingers move horizontally</p>	<p>Roll horizontally</p>
 <p>two fingers move out from center</p>	<p>Zoom out</p>
 <p>two fingers move in from two sides</p>	<p>Zoom in</p>
 <p>three fingers click</p>	<p>Active Cortana</p>
 <p>three fingers slide downward simultaneously</p>	<p>Show desktop</p>

Using in Android system

Gesture illustration&description	Gesture function
 One finger moves	Move mouse cursor
 One finger clicks once	Mouse left key clicks
 Two fingers click once	Mouse right key clicks

Power Saving Mode

The keyboard will enter sleep mode when idle for 1 minutes.
To activate it, press any key and wait for 3 seconds.

Charging

When the battery is low, the indicator will turn red. If there is no light displayed at all, the battery is completely drained. For both situations, it is time to replace the battery.

Caution

When not in use for a prolonged period of time, it is recommended that you turn off the keyboard to lengthen the battery life.

Questions? Comments? Contact us at support@vilros.com or call 1-855-207-9254