




ASSEMBLY INSTRUCTIONS



These assembly instructions are only applicable for all Base Lazy Susan ITEM No.:CB33 CB36



► General Instructions:

Thank you for purchasing a Cabinets To Go product. You are now the proud owner of a high quality product designed to face the test of daily use and guaranteeing your enjoyment for many years to come.

Carefully read the instructions before starting the installation.

During assembly, please follow all generally accepted safety procedures.

Failure to adhere to the following instructions will invalidate the warranty and Cabinets To Go will decline any responsibility for any damages caused. Any installation which does not correspond to the instructions may result in defects, malfunctioning parts, significant damage and/or injury.

Before the assembly begins, check that all appropriate and required plumbing and electrical connections exist.

Before drilling, make absolutely sure that there are no pipes (gas, water, electricity, heating, etc.) at the drilling location. Cabinets To Go will not be held responsible for failure to follow these instructions.

PRIOR TO ASSEMBLY, PLEASE MAKE SURE YOU HAVE ONE FACE FRAME BOX AND ONE CARCASS BOX, WHICH HAVE ALL THE PARTS IN THE QUANTITIES MENTIONED BELOW. IF YOU ARE MISSING ANY PARTS, PLEASE STOP AND CONTACT CUSTOMER CARE IMMEDIATELY AT 1-800-CABINET.


▶ Items Quantity


A Doors B Back Panel C Side Panels (Left & Right) D Bottom Panel E Back Side Panels (Left & Right) F Toe Kicks G Top Brace (Long) H Top Front Brace I Shelf	2
C Side Panels (Left & Right) D Bottom Panel E Back Side Panels (Left & Right) F Toe Kicks G Top Brace (Long) H Top Front Brace I Shelf	
D Bottom Panel E Back Side Panels (Left & Right) F Toe Kicks G Top Brace (Long) H Top Front Brace I Shelf	1
E Back Side Panels (Left & Right) F Toe Kicks G Top Brace (Long) H Top Front Brace I Shelf	2
F Toe Kicks G Top Brace (Long) H Top Front Brace I Shelf	1
G Top Brace (Long) H Top Front Brace I Shelf	2
H Top Front Brace I Shelf	2
I Shelf	1
-	1
	1
J Lazy Susan Trays (with Hardware)	2
Hardware Box Hinges 4pcs, Bumpers 4pcs, 2/3" Flat Head Screws 8pcs, 2/3" Round Head Coarse Thread Screws 16pcs, Cam Locks Male & Female 32pcs, Wooder	n Dowels 20pcs, Shelf Pins 8p
1 1/4" Coarse Thread Screws 5pcs	

► Required tools:











► Hardware Box:




The materials listing above are for the largest unit in this instruction set. Smaller units may require less hardware and materials; therefore, your item may contain a smaller number of each.


►Instructions:


- 1. Unpack box & identify pieces on Page 2. Place side panel (C2) onto a soft work surface. (Figure 1)
- 2. Install metal male cam locks (e) into designated holes on side panel (C2), back side panel (E2), front brace (H), and bottom panel (D). Use screwdriver to tighten. Install the wooden dowels (f) into designated holes. (Figure 2)







3. Install toe kicks (F) onto bottom panel (D).









- 4. Assemble the parts from Step 2 together (Figure 2) using the procedure from (Figure 4) by installing locking lugs (e) into the designated holes, and then lock them.
- 5. Repeat the processes above for the now assembled parts by assembling them onto the side panel (C2). (Figure 3)
- 6. Install back side panel (E1) using the same processes as before. (Figure 5)
- 7. Install the remaining side panel (C1) to the back side panel (E1) and toe kick (F). (Figure 6)
- 8. Install the back panel (B) using screws (h). (Figure 6) Then stand the cabinet upright.



9. Assemble the Lazy Susan Tray (J) to the Shelf (I) using the provided hardware.



10. Install hinges onto door into designated holes using screws provided. Install door onto cabinet sides though pre-marked screw holes. Install the shelf (I) by using shelf pins (g) in the location you choose. Install the bumpers (b) onto the door corners opposite of the hinges.



► Maintenance

For daily cleaning, use a dry cloth and a soft liquid cleaner.

Never use abrasive cleaners containing acetone, chlorine or strong bleach. Also, do not use tools as scrapers, metallic brushes, and other products which can scratch or tarnish surfaces.

Under no circumstances should you use chrome cleaner on chrome-plated or brass trim, hinges, handles, sockets etc.

Good ventilation is essential for maintaining the quality and look of this furniture.

Warranty and Customer Care Information

For the most up to date warranty information for your product, please visit our website - www.cabinetstogo.com to get the specific details. If you have any questions with warranties or to make a claim, please contact Customer Care by email - customercare@cabinetstogo.com or call 1-800-CABINET.