
## MODEL PART DIAGRAM

## FRONT BACK Control Panel Air Outlet Vent Smart Sensor Front Panel Power plug PACKAGE CONTENTS 360º All-in-One User

True HEPA Filter

## WHERE TO USE



Allow 12 ~ 18 in. of space between TVs, radios, and other electronics Electromagnetic interference from certain electronics may cause product malfunction

Manua

Place indoors away from direct sunlight Direct exposure may cause product malfunction or failure.

Only place on hard, flat surfaces Flimsy or slanted surfaces may result in abnormal noise and vibrations. Allow 12 ~ 18 in, from walls For maximum air flow.

03. Activated Carbon Filter

pets, and smoke

04. PlasmaWave®

Reduces VOCs and household odors from cooking.


PlamaWave creates Hydroxyls which can help to

Staphylococcus aureus, Salmonella typhimurium).

reduce the presence of airborne Bacteria, Viruses\*

(\*Based on independent laboratory test conducted on

Influenza A Virus H3N2, E. coli, Pseudomonas aeruginosa,



#### 01. Filter Replacement Indicator

**CONTROL PANEL** 

LED light indicates when it is time to change the filter.

#### 02. Filter Reset Button

After replacing the 360° All-in-One True HEPA Filter, use a small object such as a paper clip, to press and hold the Filter Reset Button for at least 5 seconds until the Filter Replacement Indicator turns off.

2

#### 03. Auto Mode Button

- The unit will default to Auto with  $\mathsf{PlasmaWave}^{\otimes}$  enabled when first powered on.
- · Auto Mode automatically adjusts fan speeds according to your indoor air quality. The fan speed will adjust to low when air quality is good, medium when fair, and to high when poor.

04. Air Quality Indicator

#### 05. Sleep Mode Button

#### 06. PlasmaWave® Button


#### 07. Fan Speed Indicator Buttons

Indicates the current fan speed.

08. Power Button

Blue, Amber and Red colors operation begins.

## **4-STAGE AIR PURIFICATION**



1

01. Fine Mesh Pre-Filter

Designed to catch larger airborne particles found indoors.

#### 02. True HEPA Filter

Captures 99.97%\* of airborne allergens including; pollen, mold spores, dust, pet dander, microbes, and smoke (\*Particles as small as 0.3 microns in size).

## MAINTENANCE

### When to Replace Filters 幻

Filter	Indicator Light	When to service	When to replace
360° All-in-One True HEPA Filter	Check Filter	Clean once every 14 days	Lasts Approx. 12 months

- · When the Check Filter indicator LED is on, it is time to replace the All-in-One True HEPA Filter.
- Intervals between filter replacement may vary depending on environment.

## **INITIAL OPERATION**



Turn the product upside down.




2. Grab the handle at the bottom of the product, turn counter-clockwise, and pull out the filter cover.




3. Remove the protective vinyl from the filter installed inside the product.



4. Install the filter top side down into the bottom of unit until it is fully inserted. The top of the filter shows the








Return the product to an upright position and 6



## **CLEANING CARE**

Cleaning the Filters:

- · Only clean the Pre-Filter.
- depending on the air quality.























- This filter CAN NOT be washed
- Intervals between filter cleaning may vary

# NOTICE

Do not use benzene, alcohol, or other volatile fluids, which may cause damage or discoloration.

Color coded LED light indicates one of three levels of Air Quality: Red (poor), Amber (fair), and Blue (good).

When Sleep Mode is activated, the Air Quality Indicator LED light is disabled. • Fan speed will automatically set to minimum speed (lower than 'Low') which will be nearly silent. • When Sleep Mode is active, PlasmaWave® will be disabled, but it can be turned back on.

Enables or disables PlasmaWave®

"When the unit is running, you may hear a chirping or buzzing sound. The sound is from large particles passing through PlasmaWave<sup>®</sup>, it is normal and does not signify product failure." Press the PlasmaWave<sup>®</sup> Technology button when the unit is on to enable or disable this feature.

• Use the Fan Speed arrow buttons to set the desired fan speed. Fan speeds cycle over in this sequence: Auto, Low, Medium, High, Auto.

Low Medium High



Turns the unit on or off. During the first 30 seconds of power, the Air Quality Indicator will cycle through

· Odor Sensor takes approximately 4 minutes to detect the air quality in the environment before normal

3

## **REPLACING FILTERS**





Clean with a vacuum or a soft brush.



After replacing a filter, press the Filter Reset Button for at least 5 seconds.

Cleaning the Exterior & Interior:



Wipe with a soft damp cloth using room temperature water. Afterwards, wipe it down with a clean dry cloth. After turning the product upside down, remove the filter cover and clean the interior with a vacuum cleaner. • For optimal performance, clean every 14 days.

## NOTICE

- When cleaning the unit, always unplug the power cord first and then wait until the unit has cooled down.
- · Never disassemble, repair, or modify this unit yourself.
- Do not use flammable sprays or liquid detergents.
- Do not allow children to clean or maintain the unit.
- Before cleaning or maintaining, ensure unit is unplugged.

## SAFETY AND CAUTIONS

Before operating this equipment, carefully read and follow these safety cautions.

Ensure filters are inserted before running unit Running the unit without filters may shorten the lifespan of the unit and cause electric shock or injury.

Be sure foreign objects are NOT inserted into the vents on the unit Objects can include pins, rods, and coins.

Do not touch any part of the interior of the unit with wet hands

The high voltage may cause electric shock. Ensure unit intake and outlet vents do not become blocked Blockage may lead to increased internal temperatures,

causing product failure and deformation. Do not use the unit as a step stool or place heavy objects on it

Personal injury may occur or product failure and deformation.

When turning the product upside down, install the filter with care in the direction that the bottom (blocked) side of the filter is visible from the top If the filter direction is not installed properly, it may cause product damage and user injury.

### WARNING

Follow these instructions to reduce the risk of serious injury or death and to reduce risk of damaging the unit.

- If the power cord is damaged, it must be replaced with a special cord. Assembly available from the manufacturer or its service agent.
- This appliance is not intended for use by a person (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This unit is not intended to be used to preserve documents or in art conservation.

- Do not pull on the power cord when unplugging the unit.
- Do not tie or knot the power cord when unit is in operation.
- If the unit becomes submerged in water, unplug it and contact customer service.
- Do not unplug or move the unit while in operation
- Do not plug additional appliances into the same outlet or power supply.
- Do not touch the plug with wet hands.
- Unplug the unit when not in operation for extended periods of time.
- Do not place around heating elements.
- Do not use around mist or fumes from industrial oil or around large quantities of metallic dust.
- The cord can become damaged by forcefully bending, pulling, twisting, bundling, pinching or placing heavy objects on it.
- Do not install in any sort of motor or transport vehicle (trucks, boats, ships, etc.).
- Do not place in an area with excessive amounts of noxious gases.
- Do not place near any flammable materials (aerosols, fuel, gases, etc.).
- Do not have the unit facing into wind or drafts.
- Do not place below any electrical outlet.
- Do not place in excessively humid areas where the unit may become wet.
- To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
- Do not place unit closer than 12 inches from the wall during operation. It may cause condensation on the wall and the surrounding area.

## SAFETY INSTRUCTIONS

Thank you for purchasing a Winix air purifier. This product is for household use only.

### IMPORTANT CAUTIONS FOR USING YOUR AIR PURIFIER

· Do not repair or modify the unit. All repairs should be

The plug for this unit is polarized with one blade wider

than the other. Do not force the plug into an electrical

not fit into the outlet, reverse the plug. If it still does

• Do not use if the power cord or plug is damaged or the

• Do not damage, break, forcefully bend, pull, twist, bundle,

This will reduce the risk of shock due to humidity build up.

IMPORTANT PRECAUTIONS FOR USING YOUR AIR PURIFIER

coat, pinch, or place heavy objects on the power cord.

• Remove the power plug from the outlet before cleaning

the unit. When removing the power plug, grasp by

holding the plug itself, never hold by the cord.

Do not block the intake or outlet vents.

Do not use the unit on its side

such as a deep fryer.

· Do not use near hot objects, such as a stove.

· Do not use where the unit may come into contact with

Keep away from products that generate oily residue.

· Periodically remove dust from the power plug.

outlet. Do not alter the plug in any way. If the plug does

not fit, contact a qualified technician to install a proper

completed by a gualified technician.

connection to the wall outlet is loose.

outlet.

• Use AC 120 V only.

WARNING: Follow the instructions in this manual to reduce the risk of electric shock, short circuit, and/or fire.

- If the power plug is damaged, it must be replaced by the manufacturer or a qualified technician.
- Remove the power plug from the outlet when not in use.
- Do not handle the power plug with wet hands
- Do not operate the unit when using indoor smokegenerating insecticides.
- Do not clean unit with benzene or paint thinner.
   Do not spray insecticides on the unit.
- Do not use the unit where it is humid or where the unit may become wet, such as the bathroom.
- Do not insert fingers or foreign objects into air intake or outlet.
- Do not use the unit near flammable gases. Do not use near cigarettes, incense, or other spark-creating items.
- Unit will not remove carbon monoxide emitted from heating appliances or other sources.
- Do not use detergent to clean the unit.
- Do not operate without a filter.
- Do not wash and reuse the True HEPA Filter.
- Hold the handle on the back of the unit to transport.
- Do not hold by the front panel.
- Do not stick any small objects in the air outlet vents or fan.

Use & Care Guide

ergy

Model

## FREQUENTLY ASKED QUESTIONS

#### The unit does not turn on at all

- Is the plug securely attached to the outlet?
- Make sure the outlet has power going to it and ensure the plug is secured.
- Is there a power outage?
- Check to see if other lights and electrical equipment are working and try again.

## The unit doesn't work in Auto Mode

- Has Auto Mode been selected?
   Press the Fan Speed button until Auto Mode is selected
- Is the sensor blocked or clogged?
- Wipe Odor Sensor with wet cloth, then dry.

### It vibrates and makes a lot of noise

Is it running on a slanted or uneven surface?
 Move the unit to a hard, flat, even area.

## **PRODUCT WARRANTY**

The terms of the warranty are as follows.

- 1. This product is manufactured under stringent quality control and inspections.
- 2. The warranty will be voided if product failure is a result of negligence or misuse by the consumer.
- 3. A proof of purchase must be presented upon claiming a Product Warranty.
- Store the proof of purchase in a safe place or register your product on winixamerica.com to upload your proof of purchase.
- 5. This warranty is valid only in the USA and Canada. \* for more information visit
- \* for more information visit https://winixamerica.com/terms-and-conditions/

### The power plug and outlet feel hot

7

q

- Is the plug securely plugged in?
- Make sure the plug is properly plugged into the outlet. There is a strange smell
- Is it being used in a place with a lot of smoke, dust, or odors?
- Clean the air intakes on either side and clean the Pre-Filter.
- Replace the 360° All-in-One True HEPA Filter.
- The fan strength is weak. The unit is not purifying the air Is the Check Filter Indicator light on?
  - Change the filters as required.

### The display panel is dim

- Is the Light Sensor blocked by debris?
- When Auto Mode is on, Sleep Mode is automatically activated when the Light Sensor detects that the room is dark.

Product Name		Air Purifier
Model Name		A231 / A230
Purchase Date		
Warranty Period		Two (2) Years
Place of Purchase		
Place of Purchase tel.		
Customer	Address	
	Name	
	Tel.	

## UNIT SPECIFICATIONS

Model Name	A231 / A230
Power Voltage	AC 120 V / 60 Hz
Power Rate	55 W
Verified Room Size	230 sq.ft.
Dimensions	9.5 in(W) x 9.5 in(D) x 14.6 in(H)
Weight	6.75 lbs
Replacement Filter	FILTER 0/SKU: 1712-0110-00

8

The exterior, design, and product specifications may be changed without prior notice to improve product performance.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- + Consult the dealer or on experienced radio / TV technician for help.

This device contains license-exempt transmitter(s) / receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

"In French: Cet appareil contient des émetteurs/récepteurs exemptés de licence et conformes aux normes Innovation, Science et Economic. RSS(s) sans licence de Développement Canada. Le fonctionnement est soumis aux deux conditions suivantes:

· cet appareil ne doit pas causer d'interférences nuisibles, et

cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant provoquer un fonctionnement
non souhaité."

10

User Manual

# WINIX

# **AIR PURIFIER**



### A231 / A230

- The product warranty is printed on the back of this guide.
- This product is manufactured for use only in USA / CA.
- This product is suitable for 120 V only.

The energy efficiency of this ENERGY STAR certified model is measured based on a ratio between the model's CADR for smoke and the electrical energy it consumes, or CADR/Watt.







## WINIX

 Contact Winix for
 • Dedicated Call Center: T (877) 699-4649

 product related inquiries
 • Website: www.winixamerica.com

 and customer service
 • Website: www.winixamerica.com

To expedite service, please specify the model name and number, the nature of the problem, your contact information, and your address.

2610-0262-00 Rev.02