



DESIGNED FOR HUMAN PERFORMANCE

## RH NEW LOGIC

An RH chair is the perfect work tool, a chair that puts you in an optimal position all day, every day. A few simple adjustments is all it takes to make your RH chair fit your individual anatomy. RH chairs support an upright posture and active sitting, increasing your performance.

### Ergonomics

Providing complete support in any working position, enabling you to always sit correctly and breathe properly.

- The seat has rounded front and waterfall edge to reduce pressure on thighs. The depth of the seat can be adjusted separately.
- Sculptured shape provides comfort, keeps the back upright and gives support in any position. The pronounced "Tvedt cushion" encourages movement, upright position and open posture.
- Separately adjustable backrest angle for support in any position. Defined support for the lower back and with inflatable lumbar pump as standard.
- Pictograms on all handles and levers make the chair easy to use, easy to understand. The controls can be accessed even when seated.
- Comfort layer as standard gives increased comfort feel.
- Frictional tilt mechanism follows your every movement, easily lockable in any chosen position. The tilt resistance is quickly adjustable from 40 kg – 150 kg in 7 turns.
- Armrests are optional and adjustable (height, width, depth and turnable) The optional neck rest can be adjusted in height and depth.
- Easily interchangeable seat and back that can be clicked on and off.

### Quality

- 10 year guarantee

Flokk is certified in accordance to:

- ISO 9001
- ISO 14001

RH New Logic is certified in accordance to:

- EN 1335-1-2-3 Class A

### Environment

- In compliance with Flokk's environmental profile and credibility (CSR)
- Easy to disassemble and no glue or harmful chemicals
- EPD (ISO14025)

### Design

Materials and surfaces communicating comfort and wellbeing through bodyfitting forms. Expressing human performance.

### Fire classifications

Foams and standard fabrics are tested to BS/EN 1021-1&2 (cigarette & match). Foam and fabric according to BS-5852 ignition source 5 (crib 5) can be delivered on request. Please contact our customer service for further information.

### Maintenance

Vacuum clean the chair with a furniture brush or wipe it with a clean cloth or sponge slightly dampened with lukewarm clean water. Do not remove any plastic parts or attempt to open the seating mechanism. Contact your Flokk dealer if the chair requires servicing or maintenance.

See <https://info.flokk.com/global/rh/user-guide> for RH New Logic interactive user instruction guide.



# RH NEW LOGIC

RH NEW LOGIC  
200



RH NEW LOGIC  
220



## MEASUREMENTS

	RH NEW LOGIC 200	RH NEW LOGIC 220
Seat depth with seat slide	400-499 mm	400-499mm
Seat depth	477mm	477 mm
Seat width	442mm	442mm
Seat height - standard gas stem	394-526 mm	394-526 mm
Seat angle adjustment	+8.6°/-15.5°	+8.6°/-15.5°
Height of lumbar support above the seat	153-257 mm	135-233 mm
Backrest height	518 mm	620mm
Backrest height adjustment (from seat)	581-681 mm	581-681 mm
Backrest width	431 mm	433mm
Back angle adjustment	21°	21°
Height of armrest above seat	199-315 mm	199-315 mm
Distance between armrests	318-515 mm	318-515 mm
Diameter of base	670 mm	670 mm

## OPTIONS

Neck rest Fabric  
 Neck rest Leather  
 Armrest 8L upholstered top, standard black leather  
 Armrest 8L upholstered top, other colors leather  
 Armrest 8L top in TPU  
 Uniform upholstery back and seat  
 Upholstered back shell  
 Decorative stitching (only for standard model)

Coat Hanger  
 Base 5T Polished  
 Castor for hard floors  
 Castor lockable  
 Coccyx seat  
 XL seat  
 Seat with Memory foam Q3 (available Q3 2019)

## GAS STEMS

Gas steam 4T Black  
 Gas steam B Black  
 Gas steam A Black

For other options see the RH Price List.

The design and specifications of RH Chairs' products are developed on an ongoing basis and the above formulations should not be perceived as completely final.