



381

Remote Display True-rms Clamp Meter

Quick Reference Card



Ignore rF Err