

Adventure Skottle Stainless Steel Wind Guard

What comes in the box? Two wind guard sections and three quarter inch nuts.

How to install the wind guards:

- 1: Place the Adventure Skottle upside down and remove all three eye bolts.
- 2: Place the first wind guard section with the curved side against the pan.
- 3: Line up the bent end of the guard with a leg socket and insert the eyebolt through the hole in the guard.
- 4: With the second wind guard section, line up the bent end with the next leg socket to the right.
- 5: Bring the first guard section over the second section and insert the eyebolt through both wind guard section and secure into the leg socket.
- 6: Line up the second guard section end piece to the third leg socket to the right and insert the eyebolt.
- 7: If the guards feel loose or rattle. Use the supplied nuts to secure the guard sections against the leg sockets. Finger tight is fine.
- 8: The wind guards can be left in place when the Adventure Skottle is put away.

How to use the wind guards: Point the wind guard into the wind; shielding the burner behind the guards.

Caution: The wind guards will become hot when the Skottle is in use.