INSTRUCTIONS - DISPLAY

PS1/01, PS1/03, PS1/04, PS2/01, PS2/02

MINUTES HAND

SETTING
THE TIME

1. 2. 3.

AUTOMATIC MOVEMENT - MIYOTA 82S5 - MADE IN JAPAN

3ATM/30M WATER RESISTANT

SECONDS DISK

WINDING THE MAINSPRING

Automatic winding watch can also be hand winded by turning the crown clockwise in normal position. Wind several times clockwise. It will start to move automatically.

SETTING THE TIME

MINUTES RING

- 1. Pull the crown out to the 1st click position.
- 2. Turn the crown to set hour and minute hands.
- 3. After the time has been set, push the crown back to the normal position.

TIME READING

DISPLAY (12H)

EXAMPLE 1



10:08:10

HOURS: (10AM OR PM

MINUTES: (O8MIN)

SECONDS: (10s)

EXAMPLE 2



5:33:54

HOURS: (5AM OR PM

MINUTES: (33MIN)

seconds: (54s)