


INSTRUCTIONS - **DISPLAY**

PG1/01



AUTOMATIC GMT MOVEMENT - MIYOTA 9075 - MADE IN JAPAN


5ATM/50M WATER RESISTANT

WINDING THE MAINSPRING

1. Manual winding, rotate the crown clockwise at normal position (A.). Fully wound up by turning the crown minimum 55 times. It will start to move naturally after shaking slightly.

TIME SETTING - DISPLAY 24H / 12H

EXAMPLE 1



HOME TIME

10:05:25
(ZURICH) GMT +2



TIME

10H
(10 AM)



MINUTES

5 MIN



DATE

27TH

LOCAL TIME



12:05:25 PM
(DUBAI) GMT +4


> 10:05 in Zurich → 12:05 in Dubai

SETTING THE DATE / TIME

1. First adjust to **home time** (e.g. Zurich) with the 24H disc. Pull out the crown to the second click position (C.) and turn the crown upwards or downwards. Pay attention whether it's AM or PM. Once set pull back the crown to normal position (A.).
2. To set the date, pull out the crown to the first click position (B.) and turn the crown upwards or downwards. Once set pull back the crown to normal position (A.).
3. To adjust the hour hand to **local time** (e.g. Dubai), pull out the crown to the first click position (B.) and turn the crown upwards or downwards by one hour increments. This movement allows to change the hour hand without affecting other Hands/Discs. Once set pull back the crown to normal position (A.).

TIME SETTING - DISPLAY 24H / 12H

EXAMPLE 2



HOME TIME

22:12:30
(ZURICH) GMT +2



TIME

22H
(10 PM)



MINUTES

12 MIN



DATE

7TH

LOCAL TIME



4:12:30 PM
(NYC) GMT -4

> 22:12 in Zurich → 16:12 in New York City

SETTING THE DATE / TIME

1. First adjust to **home time** (e.g. Zurich) with the 24H disc. Pull out the crown to the second click position (C.) and turn the crown upwards or downwards. Pay attention whether it's AM or PM. Once set pull back the crown to normal position (A.).
2. To set the date, pull out the crown to the first click position (B.) and turn the crown upwards or downwards. Once set pull back the crown to normal position (A.).
3. To adjust the hour hand to **local time** (e.g. NYC), pull out the crown to the first click position (B.) and turn the crown upwards or downwards by one hour increments. This movement allows to change the hour hand without affecting other Hands/Discs. Once set pull back the crown to normal position (A.).