
INDUSTRIAL SKILLS by:

# SEVEN FRIDAY

**V-SERIES** 


#### NFC AUTHENTICATION & REGISTRATION:




**SEVENFRIDAY** watches guarantee authenticity through scanning the integrated NFC chip, which is readable by NFC enabled devices\*.

Download the **SEVENFRIDAY** app, scan to ensure authenticity, create your account and register as the official owner.

\*The chip is completely passive, data exchange is activated and powered by the device from close distance of 2-5mm. iPhones are not NFC enabled devices.





#### WINDING THE MAINSPRING

Automatic winding watches can also be hand-wound by turning the crown several times clockwise in the normal position.




#### WATCH WINDER

Counter Clockwise 650 to 950 turns per day.

#### **SETTING THE TIME**

- 1. Pull the crown out to the 1st Click position.
- 2. Turn the crown to set the hour, minute hands and Day & Night indicator.
- 3. After the time has been set, push the crown back to the normal position.

### HOURS ADDITIONER SYSTEM



\*CLOCKWISE ROTATION

## HOW DOES IT WORK?

ADDITIONER DISK + FIXED SCALE = HOURS




0 = 0h 1 = 1h 2 = 2h 3 = 3h



0 = 4h 1 = 5h 2 = 6h 3 = 7h 4 = 8h



0 = 8h 1 = 9h 2 = 10h 3 = 11h



### **DAY & NIGHT**

INDICATOR












\*DAY AND NIGHT DISK - CLOCKWISE ROTATION

#### **SECONDS**

#### ADDITIONER SYSTEM



### HOW DOES IT WORK?

ADDITIONER DISK +
FIXED SCALE = SECONDS



00 = 0 sec. 05 = 5 sec. 10 = 10 sec. 15 = 15 sec. 20 = 20 sec.



00 = 20 sec. 05 = 25 sec. 10 = 30 sec. 15 = 35 sec.

20 = **40** sec.



00 = **40 sec.** 05 = **45 sec.** 

10 = 50 sec. 15 = 55 sec.

20 = 60 sec.

\*CLOCKWISE ROTATION

#### EXAMPLE 1



**5:32**:26)

HOURS: 4+1=(5AM)

(Day & Night indicator in the night area)

MINUTES: (32 MIN)

SECONDS: 20+06=(26S)

#### EXAMPLE 2




(13:15:13)

HOURS: □+1=(1PM)

(Day & Night indicator in the day area)

MINUTES: (15 MIN)

SECONDS: 00+13=(135)










TO AVOID DAMAGING THE SYSTEM, DO NOT USE SHARP OR POINTY OBJECTS, USE A WATCH PUSHER TOOL FOR CORRECTOR OR ANY SOFT POINTED OBJECTS.







- 1 Press to release.
- 2 Release the strap from the side slot.



#### ATTENTION

MAKE SURE YOU ARE PROPERLY AND SAFELY INSTALLED TO PROCEED STRAP CHANGE (ON TOP OF A RIGID SURFACE).







#### **ATTENTION**

TO AVOID DAMAGING THE SYSTEM, DO NOT USE SHARP OR POINTY OBJECTS, USE A WATCH PUSHER TOOL FOR CORRECTOR OR ANY SOFT POINTED OBJECTS.

#### WWW.SEVENFRIDAY.COM

All rights reserved to SEVENFRIDAY®, unless stated otherwise, this manual is forbidden to be duplicated, published or modified for any purpose or reason.