



Kontour Camber Towel Warmer Installation Guide

Code: K1023E / K1024E
25" x 38" Electric Plug-In



1 Assembly Instructions (see figure 1)

1. Check all items have been received. Read all instructions before continuing.
2. Attach feet to towel warmer using the fixings provided.
3. Level feet if necessary.

2 Electric Plug-In Connection

TURN OFF POWER SUPPLY BEFORE PROCEEDING

Do not connect the Towel Warmer to the power supply until all instructions have been read and installation carried out in accord with them. Your towel warmer is 140W (110V) and conforms to CSA standards (File ref: 2422531). Please ensure the CSA label is visible.

1. Turn off power supply.
2. Plug connector in.
3. Switch on power supply.

Warning: In case of damage or failure of the Towel Warmer the unit should be returned to the manufacturer or their distributor. The warranty of 2 years on the Towel Warmer is NOT VALID in case of improper use or installation. Product is designed for use within Canada and the United States only.

Specifications & Drawings



Model #	Description	Finish	Weight (lb)	Watts	Volts	WxH (mm)	WxH (Inches)	Metal Type
K1023E	Camber Electric Plug-In	Chrome	9.25	140W	110V	600 x 933 x 270	23.5 x 36.75 x 10.5	Stainless Steel
K1024E	Camber Electric Plug-In	Brushed Nickel	9.25	140W	110V	600 x 933 x 270	23.5 x 36.75 x 10.5	Stainless Steel

Warranty: 2 Years

Fixings: Screws, and Allen Key (if needed) are included

Care & Maintenance: A periodic wash using warm water and a soft cloth will retain the high quality finish of your towel warmer for many years to come. ON NO ACCOUNT should any household bleaches, detergents, abrasive polishes, steel wool or other cleaning agents be used on this item.

