AQUADOM

INSTALLATION GUIDE



ASSEMBLY TOOLS

















PARTS



Single Door



Double Door




Triple Door



Mounting Bracket



Shelf Clip





Bumper



USB cable





Hole Plug







Makeup Mirror

Glass Shelf







DIMENSIONS

SIZE inches

24 x 30



- A Cabinet's width
- **B** Cabinet's Height
- C Cabinet's DePth

ROUGH IN DIMENSIONS inches

 23.5×29.5

NOTE: Determine overall medicine cabinet dimensions. if recessing medicine cabinet, determine rough-in dimensions.

SIGNATURE

ROYALE

+

ROYALE PLUS

+

ROYALE

BASIC

24 x 36 23.5 x 35.5 24 x 40 23.5×39.5 30 x 30 29.5 x 29.5 29.5 x 35.5 30 x 36 36 x 30 35.5 x 29.5 36 x 36 35.5×35.5 48 x 30 47.5 x 29.5 47.5 x 35.5 48 x 36 39.5 x 29.5 40×30 40 x 36 39.5 x 35.5 60 x 30 59.5 x 29.5 60 x 36 59.5 x 35.5 72 x 36 71.5×35.5


EDGE ROYALE

SIZE inches	ROUGH IN DIMENSIONS inches
15×70	14.5 x 69.3
20 x 32	19.5 x 31.3
24 x 32	23.5 x 31.3
30 x 32	29.5 x 31.3
36 x 32	35.5 x 31.3
48 x 32	47.5 x 31.3
60 x 32	59.5 x 31.3
72 x 32	71.5 x 31.3



WIRING


* AQUADOM Medicine Cabinet as seen from the back *





The wire bracket is located at the top rig ht corner of the cabinet if viewed from the front



WIRING 1" (25.4mm) MINIMUM FROM FINISHED CEILING MINIMUM DU PLAFOND FINI MÍNIMO DESDE EL TECHO ACABADO 2.0 in i 1.1 4.5 in FIELD WIRING I CÂBLES DANS LE CHAMP **ROUGH OPENING** CAMPO DE CABLEADO **OUVERTURE BRUTE** ABERTURA EN BRUTO 1 1 1.1 MINIMUM DOOR TO FAUCET ESPACEMENT MINIMUM DE LA PORTE AU ROBINET MÍNIMO DESDE LA PUERTA AL GRIFO **ROUGH OPENING OUVERTURE BRUTE** ABERTURA RÚSTICA








HINGE ADJUSTMENT


Side Adjustment



Side adjustment of the door is made by using the indicated cam screw.








Depth Adjustment

Depth adjustment is made without loosening any screw. The door can be moved in or out by rotating the carn adjuster or fixing screw on the hinge arm.







Height Adjustment


By loosening the two fixing screws, you can allow the mounting plate to slide up or down and the door can be adjusted vertically by \pm 2mm. After adjusting, retighten the screws. If you are using a mounting plate with cam adjustment for height, simply turn the cam adjuster to align.



















AQUADOM Mirror Installation Guide

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical furnishing, basic precautions should always be followed, including the following:



READ AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS MIRROR.



ARNING Risk of electric shock. Connect this furnishing to a properly grounded circuit only. See Grounding instructions.



WARNING To reduce the risk of burns, fire, electric shock or injury to persons. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer. Never drop or insert any object into any opening. Do not use outdoors.

GROUNDING INSTRUCTIONS:

This product must be connected to a grounded metal, permanent wiring system, or an equipment-grounding conductor must be run with the circuit conductors and connected to the equipment-grounding terminal or lead on the product.



WARNING

An Electrical option cabinet must be wired to a 20 Amp GFI (Ground Fault Interrupter) protected circuit when used in bathrooms and all other locations required by the National Electric Code.

PLEASE SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE



Aquadom Guía de Instalación de Espejo AQUADOM

INSTRUCIONES IMPORTANTES DE SEGURIDAD

Cuando de está usando equipo eléctrico, precauciones básicas deben seguirse, incluyendo las siguientes:



LEA Y SIGUA TODAS LAS INSTRUCCIONES ANTES DE USAR ESTE ESPEJO.



ADVERTENCIA

Riesgo de choque eléctrico. Conecte este equipo a un circuito apropiado de tierra física. Vea las instrucciones de Aterrizado.



ADVERTENCIA

Para reducir los riesgos de quemadura, fuego, choque eléctrico o lastimar a alguien. Utilice este equipo únicamente para el uso previsto como se describe en estas intrucciones. No utilice accesorios no recomendados por el fabricante. Nunca deje caer o introduzca algún objeto dentro de cualquier abertura. No se use en el exterior.

INSTRUCCIONES DE ATERRIZAJE:

Este producto debe conectarse a una tierra metálica, a un de cableado permanente, o a un conductor de aterrizaje de equipos que debe correr con el circuito de conductores y conectados a una terminal general de aterrizaje de equipos.



ADVERTENCIA

Una opción eléctrica para el gabinete deba estar cableado a un circuito protejido con un Interruptor de Falla a Tierra (GFI) de 20 Amp cuando se usa en baños y en todas aquellas ubicaciones que requieran la aplicación del Código Eléctrico Nacional (NEC).

POR FAVOR GUARDE ESTAS INSTRUCCIONES PARA REFERENCIA POSTERIOR

FINAL ASSEMBLY

ITEM	MODEL	FEATURE
	SIGNATURE ROYALE	3D Lighting,Dimmer Switch,Defogger,Digital Clock , Outlet with USB port,Makeup mirror , Interior light
	ROYALE PLUS	Cold light,Dimmer Switch,Defogger, Outlet,Makeup mirror , Interior light
MEDICINE CABINET	EDGE ROYALE	Cold light, Dimmer Switch, Defogger, Outlet, Makeup mirror, Interior light
	ROYALE BASIC	Cold light,Dimmer Switch
	PACIFICA	Cold light,Dimmer Switch,Defogger, Outlet
	DAYTONA	3D Lighting, Dimmer Switch, Defogger, Digital Clock
MIRROR	ѕоно	Cold light,Dimmer Switch,Defogger
	EDGE	Cold light,Dimmer Switch,Defogger

3D Lighting	Blue-cood 6500kelvin	· ·
	Yellow-Warm 3000kelvin	
	White-Mixed 4600Kelvin	

1. Touch the Light button in order to turn the lighting mechanism on.



- 2. Touch the Light button again in order to chose the desired light .(Cool ,Warm,Mixed)
- 3. Touch and Hold the button in order to dim the currently selected light.



Cold light	6500kelvin	ROYALE PLUS,EDGE ROYALE,ROYALE BASIC,PACIFICA,EDGE
------------	------------	--

1. Touch the Light button in order to turn the lighting mechanism on.



2. Touch and Hold the button in order to dim the currently selected light.

- 1			
	Cold light	6500kelvin	ѕоно

1. Touch the Light button in order to turn the lighting mechanism on.



- 2. Touch the Light button again in order to chose the desired light . (Surface light ,Backlight , Mixed)
- 3. Touch and Hold the button in order to dim the currently selected light.

Defoager Button:

Defogger button can be found on the inside of the cabinet. Top part of the frame. Mirror Defogger is found on the bottom middle of the frame

How to Customize the Digital Clock

Facing the mirror place your figer on the ON/OFF button.

Press and hold the button to engage the clock's program mode.

In program mode, the clock will go through 4 number fields with a 3 second break inbetween.

To set the time, press the button again while the number in flashing.

The reset button can be found on the bottom of the frame under the clock.



AQUADOM Installation Guide

WARRANTY

AQUADOM warrants to the original purchaser that it will, at its election, repair, replace, or make appropriate adjustment to products made by this company shown to have significant defects in material or workmanship which are reported to AQUADOM in writing within one (1) year from the date of delivery. AQUADOM is not responsible for installation costs.

The warranty is void in the event the product is damaged in transit, or if damage or failure is caused by abuse, misuse, abnormal usage, faulty installation, damage in an accident, improper maintenance, or any repairs other than those authorized by AQUADOM.

At the expiration of the one-year warranty period, AQUADOM shall be under no further obligation under any warranty, expressed or implied, including the implied warranty of merchantability.

AQUADOM shall not be liable for any consequential damages arising out of or in connection with the use or performance of its products. Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Any liability against AQUADOM under any implied warranty, including the warranty of merchantability, is expressly limited to the terms of this warranty. Permission to return any merchandise under this warranty must beauthorized by AQUADOM and returned prepaid by the purchaser.