

# GARAGEBAND CONTROL MODE

**WORK MORE EFFICIENTLY WITH HANDS-FREE CONTROL FOR GARAGEBAND**



## The Elmore Pedal - GarageBand Control Mode

The Elmore Pedal takes the power of a GarageBand to a whole new level by enabling handsfree control, making music production and audio engineering sessions even easier, more efficient, and more enjoyable. With the ability to control GarageBand without using your hands, you can stay fully immersed in the creative process, focusing on the music and enhancing your workflow. With your Elmore Pedal, you now have the freedom to control GarageBand with your feet, allowing you to concentrate on the details and nuances of your music.

**Compatibility:** Mac

**Requirements:** Our pedal works with MacOS

	<b>Garage Band (MacOS)</b>
<i>Actions</i>	<i>Functions</i>
Right Tap	Play/Pause
Right Double Tap	Playback Advance One Bar
Right Hold	Playback Seek Forward
Left Tap	Playback Back One Bar
Left Double Tap	Start Record
Left Hold	Playback Seek Backward
Hold Both	Enter Mode Switch

- **Getting Started:** To use the Elmore Pedal, you will need to download and install the newest version of our firmware stored in the memory chip of the our pedal.
  - i. Click "[Support](#)" or go to [www.elmorepedals.com/pages/support](http://www.elmorepedals.com/pages/support)

