

MUESCORE CONTROL MODE

WORK MORE EFFICIENTLY WITH HANDS-FREE CONTROL FOR MUESCORE



The Elmore Pedal - MuseScore Control Mode

The Elmore Pedal takes the power of MuseScore to a whole new level by enabling handsfree control, making music production and audio engineering sessions even easier, more efficient, and more enjoyable. With the ability to control MuseScore without using your hands, you can stay fully immersed in the creative process, focusing on the music and enhancing your workflow. With your Elmore Pedal, you now have the freedom to control MuseScore with your feet, allowing you to concentrate on the details and nuances of your music.

Compatibility: Mac

Requirements: Our pedal works best with MacOS

	MuseScore	MuseScore Mobile Device
<i>Actions</i>	Functions	Functions
Right Tap	Next Page	Page Forward
Right Double Tap	Next Note	None
Right Hold	Page Forward	None
Left Tap	Previous Page	Page Backward
Left Double Tap	Previous Note	None
Left Hold	Page Backward	None
Hold Both	Enter Mode Switch	Enter Mode Switch

Getting Started: To use the Elmore Pedal, you will need to download and install the newest version of our firmware stored in the memory chip of the our pedal.

1. Click ["Support"](#) or go to www.elmorepedals.com/pages/support

 **WWW.ELMOREPEDALS.COM**

 **INFO@ELMOREPEDALS.COM**

 **@elmorepedals**

