Smoke Pump Instructions

(When Using the Pipe as a Smoke Pump)

Note: Make sure large and small washers are on all threaded pieces as shipped to you. Do not over tighten the pipe as its design allows for no air loss. Always test your pipe for air loss by blowing into the mouthpiece of the fully assembled pipe and covering the top bowl and the remaining mouthpiece with your fingers. If you can't blow air into the pipe, your pipe is working at 100%. When you disassemble then reassemble your pipe, always screw the large bowl (#4) on first into the 4 hole square piece (#5) before screwing in any other parts into the 4 hole square piece (#5).

- 1) Place the 2 batteries into the air pump (2 batteries are included).
- 2) Remove the top bowl (#4) on the pipe. The hole where the bowl was removed will later be the ignition/flame hole.
- 3) Unscrew the bottom small cap (#6) from the 4 hole square piece (#5) and insert the handle (#7). Fasten the handle securely.
- 4) Unscrew the center adapter (#9) from the large bowl (#10).
- 5) Make sure a silver screen is in the large bowl (#10) and the screen is clean. A silver screen was placed in the large bowl (#10) prior to shipping. Fill the large bowl (#10) with tobacco and then screw the center adapter (#9) and large bowl (#10) back together. Tobacco quantities you put in the chamber vary on the burn time desired. Both bowls (#8 and #10) can be filled with tobacco for longer burn times. Slightly compact the tobacco towards the large bowl (#10).
- 6) Attach the pump hose (#19) to the pump (#15). Attach other end of pump hose (#19) to the mouthpiece (#1). This is the end of the pipe towards the 4 hole square piece.
- 7) Place a plastic finger tip (#20) on your index finger. 3 finger tips are included. Choose the tip that fits best. The top of each finger tip has a finger nail hole if needed.
- 8) Turn the pump (#15) on.
- 9) Holding the pipe by the handle (#7), place the pipe at a 45 degree angle allowing for the flame to burn up into the chamber. Light the top ignition/flame hole on the top of the 4 hole square piece (#5) where the bowl (#4) was previously removed. Inhale through the mouthpiece (#13) at the long stem end of the pipe.
- 10) Once ignited regulate the airflow by placing your index finger on and off the ignition/flame hole.
- II) To use your mask after the pipe is lit, simply place the mask hose (#17) onto the pipes long end mouthpiece (#13).

Note: To ignite the Smoke Pump directly from the mask insert the plastic piece (#14) inside of the mask into the mask insert (#18). Follow steps 1 through 9. Place the 2 foot mask hose (#17) on the mouthpiece (#13) and the mask (#16). Strap on the mask and ignite the pipe at a 45 degree angle inhaling through the small tube (#14) inside the mask. Once the Smoke Pump is lit release the small tube from your lips allowing the smoke to flow through the mask, regulating the air flow with you index finger on the ignition/flame hole.