
H O U S E S I G N C O








Position your sign into the desired location, use a spirit level to ensure it is straight, then mark the centre of the holes.



Drill your holes using a 6mm masonry drill bit and insert the wall plugs.

We advise drilling a pilot hole first with a smaller drill bit (this helps to prevent drifting which can affect the alignment of the holes and prevent your sign from sitting correctly once installed).

Step 3



Place your sign into position and fix into place with the screws.

Don't over-tighten the screws and take care not to slip with the screwdriver and damage the face of the sign.

Tip: Choose a level area to mount your sign ensuring you're going to be drilling into solid flat brickwork, we don't advise using brick joints as a mounting position.

If you're fixing your sign to wood simply screw direct without using the wall plugs.

$H O U S E S I G N \bigcirc O$

About Slate

Slate is a beautiful natural product which features slight imperfections and variations to its surface. All of our slate signs are permanently engraved with a paint infilled finish, which will not fade or discolour, providing you with a beautiful long lasting house sign.

No two signs will look the same making each sign a unique statement for its home.

Slate Care

Prior to leaving us your sign has been oiled for a beautiful dark finish. Slate signs require minimal maintenance however if you need to clean your sign please only use soapy water and a soft cloth. Use of abrasive cleaners or harsh chemicals may scratch and/or discolour the surface. Over time the surface may begin to dull slightly, if you want to darken the surface and add a shine again then we recommend using a small amount of teak oil to restore the lustre (ensure the sign is clean and dry before application of any oil).

Unfortunately your screws won't last as long as your sign, at the first sign of corrosion please replace them to prevent staining to the face of your sign. Replacements can be purchased inexpensively from any general hardware store.

For any questions please contact us at sales@housesignco.co.uk