



## GeoPlanter Dimensions and Compatible Trays

### Outer Dimensions

48 x 96 GeoPlanter	47 in. x 95 in. x 12 in.
48 x 48 GeoPlanter	47 in. x 47 in. x 12 in.
36 x 36 GeoPlanter	35 ¼ in. x 35 ¼ in. in x 12in.
72 x 36 GeoPlanter	70 ½ in. x 36 x 14 ¼ in.

---

### Internal Dimensions

48 x 96 GeoPlanter	46 in. x 94 in. x 12 in.
48 x 48 GeoPlanter	45 in. x 45 in. x 12 in.
36 x 36 GeoPlanter	32 ¾ in x 32 ¾ in. x 12 in.
72 x 36 GeoPlanter	68 in. x 33 ½ in. x 14 1/4

---

### Trays Compatible with GeoPlanters

- Botanicare OD Trays
- Botanicare ID Trays
- ActiveAqua Standard, Premium
  - GeoPlanters are NOT compatible with the 'Economy' Trays or Low Rise Trays
- Any Tray with Internal or External dimensions greater than or equal to the corresponding values listed above.