

32



33



CONVERTING YOUR DOUBLE DRIVE WHEEL TO SINGLE DRIVE: The double drive spinning wheel has both single and double drive options. When spinning single drive loosen the drive band tension and place both drive bands over the large flyer whorl. Check the drive band tension. Place the brake band over the bobbin whorl and turn the brake band tension knob until the springs just begin to stretch.
Note: The brake band is not required when spinning double drive.

Happy spinning!