

## Schlage - ND Locks



### *ND73PD ANSI F90*

#### **Corridor Lock**

Locked or unlocked by key from outside. Push button locking from inside. Turning inside lever or closing door releases button. When outside lever is locked by key it can only be unlocked by key. Inside lever is always unlocked. Inside lever is always free for immediate egress.



### *ND85PD*

#### **Faculti Restroom Lock**

Outside lever fixed. Entrance by key only. Push-button in inside lever activates visual "occupancy" indicator, allowing only emergency master key to operate. Turning inside lever or closing door releases visual occupancy indicator. Rotation of inside spinner-button provides lock-out feature by keeping indicator thrown. Inside lever is always free for immediate egress.



### *ND75PD ANSI F110*

#### **Classroom Security Lock**

Key in either lever locks or unlocks outside lever. Inside lever is always unlocked. Inside lever is always free for immediate egress.



### *ND91PD ANSI F82*

#### **Entrance/Office Lock**

Push-button locking. Push-button disengages outside lever until unlocked with key or by turning inside lever.



### *ND80PD ANSI F86*

#### **Storeroom Lock**

Outside lever fixed. Entrance by key only. Inside lever always unlocked. Inside lever is always free for immediate egress.



### *ND92PD ANSI F109*

#### **Entrance Lock**

Turn/push-button locking; pushing and turning button disengages outside lever, requiring use of key until button is manually unlocked. Push-button locking; pushing button disengages outside lever until unlocked by key or by turning inside lever.



### *ND80PDEL*

#### **Electrically Locked (Fail Safe)**

Outside lever continuously locked electrically. Unlocked by key outside or by switch or power failure. Auxiliary latch deadlocks latchbolt when door is closed. Inside lever always free for immediate exit. Inside lever is always free for immediate egress.



### *ND93PD ANSI F88*

#### **Vestibule Lock**

Latch retracted by key from outside when outside lever is disengaged by key in inside lever. Inside lever is always unlocked.



### *ND80PDEU*

#### **Electrically Unlocked (Fail Secure)**

Outside lever continuously locked until unlocked by key or electric current. Auxiliary latch deadlocks latchbolt when door is closed. Inside lever always free for immediate exit. Inside lever is always free for immediate egress.



### *ND94PD ANSI F84*

#### **Classroom Lock**

Outside lever disengaged and unlocked by key. Inside lever always unlocked.



### *ND82PD ANSI F87*

#### **Institution Lock**

Both levers fixed. Entrance by key in either lever.



### *ND95PD ANSI F110*

#### **Classroom Security Lock**

Key in either lever locks or unlocks outside lever. Inside lever is always unlocked.



### *ND96DP ANSI F86*

#### **Store Room**

Outside lever always disengaged. Entrance by key only. Inside lever always unlocked.