
## ASSEMBLY AND INSTALLATION INSTRUCTIONS

## AL-PDD360

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. READ AND SAVE THIS INSTRUCTION.





Socket Ring

THE REAL PROPERTY.