


# X-MAX II Pro



## USER MANUAL

### Portable Baked Vaporizer

#### DISCLAIMER

Read and follow instructions carefully. Understand fully before first use your X-MAX II. We recommend you keep these instructions in a safe place for future reference.

You must be over 18 years old to purchase or use X-MAX II Vaporizer Pen.

X-MAX II Vaporizer Pen is not a medical device and is not intended to diagnose, cure, treat or prevent any diseases or other conditions. If you have any health problems, consult your doctor before using the X-MAX II Vaporizer Pen.

This product should not be used by children, women who are pregnant or breast feeding, or those with life threatening illnesses without first consulting a doctor. Also should not be used before driving or operating machinery.

X-MAX II Vaporizer Pen is not intended to administer medicinal or illegal substances of any kind. Any illegal use of this device could subject the user to severe fines, penalties, and/or imprisonment under the law of your jurisdiction.

THIS PRODUCT DOES NOT CONTAIN TOBACCO OR ANY OTHER PLANT MATERIAL.

Thank You for purchasing the X-MAX II vaporizer pen. This vaporizer has an advanced heating chamber technology that will delight you. We hope you enjoy the quality and performance of your new vaporizer.

To ensure optimal performance and safety of your X-MAX II vaporizer pen, please read this entire manual for instructions.

## X-MAX II OVERVIEW/CONTENTS

Mouthpiece/Filter    Liquid & Waxy    Heating Chamber    Lithium Ion Battery    Battery Tube  
Cup



Packing Tool

Cleaning Brush

Wall Adapter

USB Port

Tweezer

## SPECIFICATIONS

Capacity	18650 3.7V 2200mAh 10C
Battery Voltage	3.5V- 4.2V
Charger/Output Voltage	5.0V/ 500mAh
On/Off	Click the button 3 times consecutively
Safety Power Duration	X-MAX V2- 3 minutes, X-MAX V2 Pro- 5 minutes
Battery Low	LED lights flash 10 times rapidly
Liquid/ Wax cup:	Stainless steel
Heating Chamber:	Ceramic with embedded heating element

## OPERATION GUIDANCE

1. Remove X-MAX II's rubber mouthpiece, exposing the heating chamber.
2. Always fill the chamber with moderate ground herb. Do not compress the plant material too much so that the airflow is not unnecessarily impeded. Then put back the mouthpiece.  
OR-  
if using with wax or oils, place a small amount of wax into the wax chamber, make sure the filling chamber is partially filled.
3. Click the button 3 times in quick succession. The Red, Green and White lights will flash, and then the battery level light will be displayed.  
(White light=Full Power, Green light=Med Power, Red light=Low Power)
4. Wait for the battery level indicator light to go out, then hold the button 2 seconds to select temperature, if hold more than 4 seconds it will cycle through temperatures at a faster rate.
5. The device will automatically heat up after temperature is selected.

6. The LED light will flash while heating up, and will be stable when reaching the selected temperature until it auto shuts off. Inhale slowly and deeply from the mouthpiece while the light is on.

#### Temperature Settings Light

- RED: 180°C/356°F
- BLUE: 190°C/374°F
- GREEN: 200°C/392°F
- PURPLE: 210°C/410°F
- WHITE: 220°C/428°F

#### Battery Level Display

- RED: UNDER 20%
- GREEN: UNDER 60%
- WHITE: 60-100%

**Low Power:** The red light will flash 10 times and the device will automatically shut off.

## CHARGING

To protect and extend the battery, we recommend charging your X- MAX II via Wall Adapter for at least 6 hours before the first use. It can also be charged via USB port but takes longer time. (External 18650 battery charger is available but not included.)

When charging, X- MAXII's LED lights will cycle through red, green and white to indicate the battery level. Then the white LED light will flash 10 times when X- MAX II is fully charged, before the light goes out.

If you have any concerns, or if there are any problems please switch off the vaporizer and pull the power adapter cord immediately. Do not try to remedy the defect yourself. Contact our Customer Service directly ([support@topgreencig.com](mailto:support@topgreencig.com)).

After using the vaporizer and power adapter, allow them to cool down before placing them in storage. Please store them in a dry place protected against the effects of weather and out of the reach of children or unqualified persons.

Please use original charger rather than other manufacture chargers. X- MAX II cannot be used while charging. Otherwise it will be dangerous.

## CLEANING/MAINTAINING

After long-term use, the mouthpiece might be clogged and dirty, resulting in a difficult draw or a low amount of vapor.

1. Clean the rubber mouthpiece: first remove the metal filter by squeezing the base of the rubber mouthpiece. Once removed, use a cotton swab and wipe the inner part of the rubber mouthpiece then wipe again with a damp paper towel.
2. Clean the filter: after using dry herbs, use the brush tool to gently clean the filter. For a deeper clean, use your hands or damp paper towel to gently clean the filter with a mixture of soap and water.
3. Clean ceramic heating chamber: use the brush tool to gently clean the walls of the heating chamber.

DO NOT clean the whole device by water.

DO NOT inject any liquid into ceramic chamber.

## WARRANTY AND LIMITATION

To claim under the warranty visit [www.XVAPECIG.com](http://www.XVAPECIG.com) or contact your seller.

We warrant solely to the original purchaser of the Products that within the warranty period (as defined below), the Products will be free from defects in materials and workmanship under normal use, and will conform to Company's published specifications of the Products. The foregoing warranty is subject to the proper storage, transportation and use of the Products, but does not include defects in batteries, buttons and similar parts subject to wear and tear or deterioration and other special, consequential or incidental damages. Customer agrees to accept responsibility for such risks and to not hold the manufacturers, distributors or retailers (including owners and employees) responsible for any incident, injury to persons, or damage to property.

Upon delivery, Customer should inspect the Products immediately for conformity and visible defects. If there is a quality problem, Customer shall give Company written notice of any

non-conformities or visible defects regarding the Products and contact Company in writing concerning return or repair. Our team shall provide on-site service within 24 hours after receiving Customer's written notice. Customer must provide photos/ video or other evidence as a proof within 7 days.

The warranty period for X-MAX II Vaporizer begins on the date when the Product is physically delivered to the Customer's site, and is valid for six months thereafter with a free lifetime service guarantee.

#### Warranty option

- 1.Repair the product defect
- 2.Exchange the product with a new or functionally equivalent product
- 3.The limited warranty does not apply to normal performance degradation of batteries or neglect of use and non-adherence to cleaning instructions.

#### Shipment of claim settlement

- 1.We will resend new product along with Customer's next order.
- 2.If Customer does not plan to make a new order in the short term, Customer can pay the resend shipping cost and ask to resend new product.

All requests and notices from all Customers under this warranty shall be emailed to [support@topgreencig.com](mailto:support@topgreencig.com)

**www.XVAPECIG.com**